Appendix K

Appendix S Procedures for Environmental Monitoring and Analysis

Procedures for Environmental Monitoring and Analysis

S.1 Groundwater Sampling

Groundwater sampling locations, sampling frequencies, and parameters are shown on Plan Sheet 23. A larger plan sheet than 11 x 17 is required to provide clarity to monitoring points shown across the entire landfill. WDNR General Monitoring Procedures are available in a published document entitled Groundwater Sampling Desk Reference PUBL-DG-03796 and Groundwater Sampling Field Manual, PUBL-DG-03896; both dated September 1996. Both manuals are available on the WDNR website.

Field Procedures

Measuring Static Water Level

Static water levels will be measured in each well prior to purging and sampling. Groundwater levels will be measured using a reference point established on the well casing. The reference point will be a permanently marked point of the PVC well casing. A battery-operated water level indicator (Solinst water level indicator or suitable substitute) will be the primary device for water level measurements. The indicator is a self-contained transistorized instrument equipped with a cable and sensor that activates a buzzer and a light when it contacts the water. The depth to water is read from permanent 0.01-foot increment markings on the cable.

In case of instrument failure, depth to groundwater will be measured by a plopper tape that is a bell- or cup-shaped weight attached to a nylon-coated stainless-steel measuring tape. When lowered into the well, a "plopping" or "popping" sound is made when the weight strikes the surface of the water. An accurate reading can be determined by lifting and lowering the weight in short strokes, and reading the tape when the weight just strikes the water. The total depth of the wells will be measured using the plopper tape or similar device. Depth to water will be recorded to the nearest 0.01 foot prior to any purging of groundwater

In order to prevent cross-contamination between wells, the water level measuring device will be decontaminated by rinsing with distilled water.

Groundwater Monitoring Well Maintenance

In order to assess problems and possible damage to the monitoring wells, field technicians will visually inspect wells at the time of sampling. Wells will be inspected for the following items:

- Adequate security (lock in place and in working order)
- Surface seal condition
- Presence of well cap
- Damage to the protective casing (e.g., evidence that it has been hit by heavy machinery)
- Amount of sediment in well (detected by measuring depth to bottom)
- Legible labels
- Condition of dedicated bailers, pumps, or tubing

Field technicians will provide a written inspection report to Dane County so that appropriate action may be taken if needed.

Purging Monitoring Wells

The monitoring wells will be purged by removing stagnant water so that the samples collected are of fresh formation water. Before purging each well, the amount of water in four well volumes will be calculated. The steps to calculate the purge volumes are as follows:

- Measure the depth to water and the depth to the bottom of the well, or use the last measurement of the depth to the bottom if a dedicated pump exists and the pump is not removed during the event.
- Subtract the depth to water from the depth to the bottom of the well.
- All wells are 2-inch-diameter; therefore, multiply the result obtained in Step 2 by 0.163 gallon/foot, and multiply that by 4.

Purging Private Wells

Private wells will be sampled from an outside tap, or if necessary from an inside tap located before the pressure tank, if possible. The well will be purged for at least ten minutes, prior to collecting the sample for laboratory analysis, sample collection will be the same as a monitoring well.

Sample and Data Collection at Each Well

Samples will be collected immediately after purging. If a well pumps dry, the sampler will wait until the well has sufficiently recovered to obtain a sample. The steps to sampling the monitoring wells are as follows:

- Prepare bottles by labeling with the well number, the date, the name of the sampler, and the time of day at which the sample is collected.
- 2. Set up filtering equipment.
- Collect samples using the dedicated bailers or discharge tubing. 3.
- Fill VOC vials first, followed by other unfiltered bottles in order of volatilization potential.
- After filling unfiltered bottles, collect a sample for filtering and performing field measurements.

The instruments used in the field and their calibration procedures are described below.

Specific conductance - A sample for specific conductance and temperature will be selected immediately after purging and placed in a clean polypropylene beaker for measurement. A portable specific conductance meter, YSI 556, or equivalent, will be used to measure the specific conductance of the groundwater sample. Each meter will be checked/calibrated before each field trip and daily while in the field. Batteries will be checked, and conductivity cells will be cleaned and checked for accuracy against a known standard (e.g., KCl solution at 4,490 µmhos @ 25°C). Decontamination of the conductivity probe between samples in the field will be achieved by rinsing it several times with deionized or distilled water.

YSI 556 series meter - Specifications

Range:

0 - 200 mS/cm

Meter accuracy:

 \pm 0.5% of reading or \pm 0.001 mS/cm; whichever is greater

(4-meter cable) \pm 1.0% of reading or \pm 0.001 mS/cm; whichever

is greater (20-meter cable)

Resolution:

0.001 mS/cm to 0.1 mS/cm (range-dependent)

pH - The pH of the sample will be measured in the groundwater sample collected from the well in the same beaker used for specific conductance and temperature, with all three measurements being taken concurrently. The measurements will be made

electronically using a glass combination electrode automatic temperature compensation probe included with the YSI 556, or equivalent. The measurements will be recorded to the nearest 0.1 pH unit. The meter will be checked before each field trip and daily while in the field for any mechanical or electrical failures, weak batteries, and cracked or fouled electrodes. The meter and electrode will also be checked/calibrated against standard buffer solutions of known pH values (e.g., 4.00, 7.00, and 10.00). While in the field, the meter will be checked at least prior to starting, and at the end of the day with fresh buffers. In case of an apparent discrepancy in a pH measurement, the electrode will be checked with pH 7.0 buffer and rebuffered to the closest reference buffer to the pH of the sample. Decontamination of the pH probe will be done at each well by rinsing with deionized or distilled water. A clean beaker for the field measurements will be used for each sample so as to prevent cross-contamination. The breaker will be rinsed three times with a portion of the next sample prior to obtaining a reading.

YSI 556 series meter - specifications

pH range:

0 to 14.00

Resolution:

0.01 pH units

Accuracy:

±0.2 units

Calibration:

Up to 3 points (4.00, 7.00, and 10.00)

A log of meter calibrations and checks should be maintained during each sampling event. The calibration and checks should be performed a minimum of two times a day following the procedures specified in the meter manuals. A copy of the manufacturer's manual for the YSI 556 meter is attached (Attachment S-1).

Color/Odor/Turbidity - Complete color, odor, and turbidity observations as follows:

- 1. Color: Note color before filtration against a white background.
- 2. Odor: Carefully wave your hand over the opening of the sample container and note any distinct smell. Do not smell the sample directly, particularly when dealing with hazardous or unknown materials.
- 3. Turbidity: Comment on turbidity (e.g., cloudy, turbid, clear).

Data collected during the field monitoring should be recorded on Form S-1.

Field Filtering

Filtering in the field will be required for the inorganic parameters, in order to prevent changes due to precipitation or biological activity and to collect a more representative sample of the water. In many cases, there may be a small amount of silt or clay in the water after purging the well. This sediment is not representative of constituents transported in groundwater flow systems in porous media. The filtering is performed in the field because even short delays may drastically change the water chemistry. Field filtering is performed by attaching a disposable self-encapsulated paper 0.45-micron barrel filter to the discharge of the bailer, or pump. Well water is run through the filter and collected directly into the sample container.

Equipment Cleaning Procedure Between Sampling Events

Equipment used for sampling that is not dedicated or discarded after use (meters and water level measuring devices, etc.) is decontaminated before the sampling event using the following steps:

- Prepare a soapy water bath using laboratory-grade detergent (Alconox or equivalent).
- 2. Wash equipment with soapy water bath.
- Unwind water level measuring devices, soak in soapy water, and wipe clean with a cloth.
- 4. Rinse equipment with tap water.
- 5. Rinse equipment with deionized water (ASTM Type II).
- 6. Air-dry equipment.

Equipment Cleaning Procedure Between Monitoring Wells

The procedure to be followed for cleaning water level indicators and nylon-clad steel tapes in the field between wells is as follows:

- 1. Rinse equipment with soapy water using laboratory-grade detergent (Alconox).
- 2. Rinse equipment with deionized or distilled water (ASTM Type II).

Sample Preservation Methods(1)

The preservation methods for the parameters to be analyzed are listed in Table S-1. Each of the bottles contains a premeasured volume of preservative, as needed.

⁽¹⁾ Some parameters analyzed in leachate, condensate, surface water, and/or gradient control.

Chain-of-Custody Guidelines

A Chain-of-Custody Record provides a written record of sample bottle possession and transference. An example of a typical Chain-of-Custody Record is shown on Figure S-1.

Quality Control Procedures

Trip Blanks - Trip blank samples will be prepared in the laboratory by filling the appropriate clean sample container(s) with reagent-grade water and adding any applicable chemical preservative. The containers will be labeled "Trip Blank." Trip blanks will be shipped from the laboratory in the cooler to the field and back to the laboratory along with the other samples for that parameter for a given sampling event. The trip blanks are analyzed to identify contamination that may occur from the containers, coolers, cleaning procedures, or chemical preservatives used. Trip blanks will be used and analyzed at a frequency of at least one per sampling event/cooler.

Field Blanks - Field blank samples will be prepared in the field at a routine sample collection point during a monitoring event by filling the appropriate sample containers from the field supply of reagent-grade or distilled water. The reagent-grade/distilled water will be provided by the laboratory. The field blank will be analyzed for contamination that may occur as a result of site ambient air conditions and serves as an additional check for possible contamination in the containers or coolers, and also for possible contamination owing to the cleaning procedures or the chemical preservatives used. Field blanks will be collected and analyzed as part of the sampling program.

Equipment (Rinsate) Blank - Equipment or rinsate blanks will be prepared in the field immediately following decontamination of nondedicated or nondisposable field equipment used for purging, sampling, or sample filtration. Following decontamination, reagent-grade water will be passed through the equipment using the same procedures followed in collecting a groundwater sample. The equipment blank confirms proper field decontamination procedures. Equipment or rinsate blanks will be collected and analyzed as part of the sampling program for the field filtering equipment.

Field Duplicate - Field duplicate samples are extra samples collected at a random monitoring point and labeled as "Duplicates." This is an additional sample collected from the same source, stored in separate containers, and analyzed independently. The samples will be collected in proper alternating order for the sample point and field duplicate for each parameter (e.g., first collect VOC sample, then duplicate VOC sample; then collect first metals sample, then duplicate metals sample, and so on). Field

duplicates are used to document the precision of the sampling and analytical process. Field duplicates will be collected and analyzed as part of the sampling program.

Matrix Spike/Matrix Spike Duplicate - Matrix spike and matrix spike duplicate samples are collected in the same manner as field duplicates, but allow for sufficient volume to perform both matrix spike and matrix spike duplicate analyses (triple sample volume total). To conduct a matrix spike analysis, a known amount of a target analyte is added to the sample at the laboratory prior to sample preparation and analysis. The matrix spike is used to evaluate the bias of a method in a given sample matrix.

Matrix spike duplicate samples are intra-laboratory split samples spiked with identical concentrations of target analytes. The spiking occurs at the laboratory prior to laboratory sample preparation and analysis. Matrix spike duplicate samples are used to evaluate the precision and bias of a method in a given sample matrix. Matrix spikes/matrix spike duplicates may be collected and analyzed if an expanded list of compounds requires this level of QA/QC.

Table S-1
Sample Containers, Preservatives, and Holding Times

PARAMETER	BOTTLE MATERIAL	PRESERVATIVE ⁽¹⁾	HOLDING TIME
Alkalinity ⁽¹⁾	Polyethylene	Maintain at 4°C	14 days
Chemical oxygen demand	Glass	Sulfuric acid; maintain at 4°C	28 days
Fluoride, sulfate, chloride ⁽¹⁾	Polyethylene	Maintain at 4°C	28 days
Metals and hardness ⁽¹⁾	Polyethylene	Nitric acid; maintain at 4°	6 months
Volatile organic compounds	Glass vial	Hydrochloric acid; maintain at 4°C	14 days
Nitrate+nitrite, ammonia as N, total Kjeldahl N	Polyethylene	Sulfuric acid; maintain at 4°C	28 days
BOD₅	Polyethylene	Maintain at 4°C	48 hours
Total suspended solids	Polyethylene	Maintain at 4°C	7 days
Mercury	Polyethylene	Nitric acid; maintain at 4°C	28 days
Base/neutral/acid extractable compounds	Glass	Maintain at 4°C	7 days
Cyanide	Polyethylene	Sodium hydroxide; maintain at 4°C	14 days
PCBs	Glass	Maintain at 4°C	7 days
Phenols	Glass	Sulfuric acid; maintain at 4°C	28 days

Notes:

Created by: P. Popp Checked by: N. Keller

\\NTAPB-MADISON\MSN-VOL6\-\WPMSN\PJT2\194528\0002\000005\R1945280002-001.DOCX 5/7/13

Only samples collected at groundwater monitoring wells for parameters indicated are to be field-filtered. Private wells, surface water, leachate, and gas condensate samples are not filtered.

FORM S-1

		ſ					∵ ∑	GROUNDWATER MONITORING FIELD FORM MONTH:	/ATER IMC	NITOR	ING FIELI	D FORM									
				Purgin	Purging Phase					Ш	-				Samp	Sampling Phase	Se				
Cillew	de C	Time	Top of Well Elevation	Depth to Water	Groundwater Elevation	Total Depth	Height of Water Col.	Req. Gal to Purge (4 vol.)	Amount Purged		Date	Time	рН (s.ц.)	Spec. Cond.	Temp (dea.C)	Color Before Filter	Color After Filter	Odor	Turb Before Filter	Turb After Filter	Number of Filters Used
	B		(1: MOE)		(ii: mor)						1		(iii)		(a.San)						
																				:	
																					
Casing I.D	. (inches):	Gallons p	er foot to	get one w	Casing I.D. (inches): Gallons per foot to get one well volume.					Ň	WEATHER			Wind Speed:	:pet:		Direction:		Temp. (deg.F):	9g.F):	
1.5" well :	1.5" well : 0.092 gal.	2" well	2" well : 0.163 gal.	- 1	3" well : 0.377 gal.	4" wel	4" well : 0.653 gal.	<u>-</u>		<u>a</u>	Date:				Overview:	ان					
NOTES:										Da	Date Equipment Used:	ent Used	<u>.</u>								
										됩	pH Meter:				pH 7.0:		pH 4.0:		Slope:		
										S	Spec. Cond. Meter:	Meter:			Standard:				Reading:		
										리	Temperature (deg.C):	(deg.C):									
Facility Name:	ıme:									5	Client:								Page:	Jo	
Facility Address:	dress:									Ä	Project:										
Personnel:	<u></u>									ā	Prepared by:						Date:				
										ธ	Checked by:						Date:				

UPPER MIDWEST REGION

Profile # PACE Project No. LAB COMMENTS (Lab Use Only) Invoice To Company: Date/fime: Date/Time: Invoice To Contact: Invoice To Address: Mail To Company: Invoice To Phone: Mail To Address: COMMENTS Mail To Contact: MN: 612-607-1700 WI: 920-469-2436 Quote #: CLIENT *Preservation Codes
B=HCL C=HZSO4 D=HNO3 E=DI Water F=Methanol G=NaOH eceived By: eceived By: **CHAIN OF CUSTODY** J=Other I=Sodium Thiosulfate Date/Time: Pace Analytical " H=Sodium Bisulfate Solution betseupeA sesylenA PRESERVATION (CODE)* MATRIX W = Water
DW = Drinking Water
Ovel GW = Ground Water
SW = Surface Water
WW = Waste Water
WW = Wyere
GOLLECTION FILTERED? (YES/NO) 4=None Matrix Codes telinquished By: elinquished By: DATE Regulatory A = Air B = Blota C = Charcoal O = Oil S = Soil SI = Studge Program: Rush Turnaround Time Requested - Prelims (Rush TAT subject to approval/surcharge) NOT needed on your sample On your sample **CLIENT FIELD ID** (Please Print Clearly) MS/MSD Date Needed: Data Package Options EPA Level IV EPA Level III Sampled By (Print): Sampled By (Sign): Branch/Location: Company Name: Project Number: Project Contact: Project Name: Project State: PACE LAB# Phone: PO #

ပ္ပ

Receipt Temp =

Sample Receipt pH

OK / Adjusted

Date/Time:

Date/Time

teceived By:

Date/Time:

elinquished By:

Transmit Prelim Rush Results by (complete what you want):

eceived By:

Date/Time:

Received By:

Date/Time:

Relinquished By:

special pricing and release of llability Samples on HOLD are subject to

telinquished By:

Telephone: Email #2: Email #1:

Fax:

Date/Time:

Present / Not Present Cooler Custody Seal

Intact / Not Intact

Instructions for Completing the Chain-of-Custody Record

S.1 Sample Shipment Methods

Time Period

Upon completion of the sampling event, samples will be immediately transported to the laboratory to ensure that holding times of the analyses are met.

Handling

- Samples will be iced to 4°C and contained in coolers for transport to the laboratory as soon as possible.
- 2. Transport will be by trained personnel or licensed courier service.
- 3. The container in which the samples will be transported will be a sealed cooler.
- 4. Sample packaging will include the following:
 - Place several layers of cushioning (bubble pack or similar) in the bottom of the cooler.
 - Place cushioning material around all glass bottles.
 - Fill the cooler with ice.
 - Tape the drain on the cooler shut, and wrap the cooler completely with tape in two locations.
 - Place labels reading "This Side Up" and "Fragile" on the cooler.

Sample Bottle Labels

Each sample bottle will be labeled so that the analytical laboratory has the following information:

- 1. Site identification
- 2. Sampling date and time
- 3. Sample identification or location
- 4. Sampler's name
- 5. Type of analysis to which the groundwater will be subjected
- 6. Whether the sample is filtered or unfiltered

Bottles with preservatives are color-coded by the laboratory.

Transport Container Labels

Labels for the transport containers will be addressed to the laboratory selected for analysis.

S.2 Landfill Gas Monitoring

Field Procedures

The percent methane (CH₄) and oxygen (O₂) will be monitored quarterly at currently 27 gas probe locations, as shown on Plan Sheet 23 and monthly at gas extraction wells. The phasing number and location of additional monitoring points will be determined in the POO. The following additional information will be recorded at each monitoring event:

- Temperature
- Ground condition
- Probe condition
- Barometric pressure and information as to whether the barometric pressure is rising or falling.
- Gas pressure

A portable Landtec GEM 2000 or similar gas meter will be used to perform the gas monitoring. The meter will be checked and calibrated before each field trip according to the procedures specified in the user's manual.

After the collection of the percent methane (CH₄), balance gas, and oxygen at each probe or gas extraction well, the gas monitor should be purged with fresh air to ensure that the monitor and sensor housing are free from retained gas. The percent methane and oxygen readings obtained, along with the information recorded pertaining to temperature, barometric pressure, and ground and probe condition, will be reported semiannually, along with the electronic data results.

A composite landfill gas sample, collected near the blower, will be sampled annually using analytical EPA method T015 or equal. The gas sample will be collected in a Summa® Passivated Stainless-Steel Canister after allowing the system to run for at least 1 hour.

\\NTAPB-MADISON\MSN-VOL6\-\WPMSN\P]T2\194528\0002\000005\R1945280002-001.DOCX 5/7/13

S.3 Leachate Monitoring

Leachate levels will be measured monthly at the leachate head wells, and leachate samples will be collected quarterly at the leachate lift station (Plan Sheet 23). Leachate head will be measured in the leachate head wells using a popper, or electronic water level tape. The leachate sample will be obtained using a PVC bailer or other sampling device. The leachate monitoring device will not be purged prior to obtaining samples. The samples will be treated and analyzed as described for groundwater samples, except that the leachate samples will not be filtered. Leachate volumes will be recorded monthly from the panel meter or flow meter during pumping.

S.4 Lysimeter Monitoring

The volume of liquid discharged from the lysimeters will be monitored monthly and reported semiannually. The liquid will be sampled annually and the monitoring parameters and frequency are shown on Plan Sheet 23. Sample collection will be directly from the collection line manhole or sample port. Lysimeter samples are handled and analyzed in the same manner as the groundwater samples, but they are not filtered.

S.5 Air Monitoring

A revised air permit is currently in preparation for submittal to the WDNR. The POO will present additional air monitoring information.

12

\\NTAPB-MADISON\MSN-VOL6\-\WPMSN\PJT2\194528\0002\000005\R1945280002-001.DOCX 5/16/13

Attachment S-1 YSI 556 Manufacturer's Manual





Pure Data for a Healthy Planet.®

A rugged, cost-effective multiparameter handheld system designed for the field!

YSI 556 Multiparameter System

Versatile, multiparameter handheld instrument

Rugged and reliable, the YSI 556 MPS (Multiprobe System) combines the versatility of an easy-to-use, easy-to-read handheld unit with all the functionality of a multiparameter system.

- Simultaneously measures dissolved oxygen, pH, conductivity, temperature, and ORP
- Field-replaceable electrodes
- Compatible with EcoWatch for Windows data analysis software
- Stores over 49,000 data sets, time and date stamped, interval or manual logging
- Three-year warranty on the instrument; one-year on the probes
- GLP assisting, records calibration data in memory
- Available with 4, 10, and 20-m cable lengths
- IP-67, impact-resistant, waterproof case
- Easy-to-use, screw-on cap DO membranes
- RS-232 interface for PC connection

Options to Fit Your Applications!

- Battery Options The unit is powered by alkaline batteries or an optional rechargeable battery pack with quick-charge feature.
- Optional Barometer Internal barometer can be user-calibrated and displayed along with other data, used in dissolved oxygen calibrations, and logged to memory for tracking changes in barometric pressure. (Choose 556-02)
- Optional Flow Cell The 5083 flow cell can be used for ground water applications or anytime water is pumped for sampling.
- Carrying Case The instrument comes standard with YSI 5061, a soft-sided carrying case with enough space for the 556, a 20-meter cable, and calibrating supplies. An optional 5080 hard-sided carrying case is also available.
- Confidence Solution* Quality assurance ensured. Quickly check conductivity, pH, and ORP readings with one solution.



+1 937 767 7241 800 897 4151 (US) www.ysi.com

YSI Environmental +1 937 767 7241 Fax +1 937 767 9353 environmental@ysi.com

YSI Integrated Systems +1 508 748 0366 systems@ysi.com

SonTek/YSI +1 858 546 8327 inquiry@sontek.com

YSI Gulf Coast +1 225 753 2650 environmental@ysi.com

AMJ Environmental +1 727 565 2201 amj@ysi.com

YSI Hydrodata (UK) +44 1462 673 581 europe@ysi.com

YSI Middle East (Bahrain) +973 1753 6222 halsalem@ysi.com

YSI (Hong Kong) Limited +852 2891 8154 hongkong@ysi.com

YSI (China) Limited +86 532 575 3636 beijing@ysi-china.com.

YSI Nanotech (Japan) +81 44 222 0009 nanotech@vsi.com

YSI India +91 989 122 0639 sham@ysi.com

YSI Australia +61 7 390 17223 acorbett@ysi.com

ISO 9001

EcoWatch, Pure Data for a Healthy Planet, Confidence Solution and Who's Minding the Planet? are registered trademarks of YSI Incorporated. Windows is a registered trademark of Microsoft.

©2009 YSI Incorporated
Printed in USA 0709 W11-06

YSI incorporated
Who's binding
the Planer™

5563 MPS Sensor Specifications

Dissolved Oxygen (mg/L)

Temperature

Salinity

Dissolved Oxygen Sensor Type Steady state polarographic (% saturation) Range 0 to 500% air saturation

Accuracy 0 to 200% air saturation, \pm 2% of the reading or \pm 2% air saturation,

whichever is greater; 200 to 500% air saturation, ± 6% of the reading

Resolution 0.1% air saturation

Sensor Type Steady state polarographic Range 0 to 50 mg/L

Accuracy 0 to 20 mg/L, \pm 2% of the reading or \pm 0.2 mg/L, whichever is greater;

20 to 50 mg/L, \pm 6% of the reading

Resolution 0.01 mg/L

Sensor Type YSI Temperature Precision thermistor

 Range
 -5 to 45°C

 Accuracy
 ± 0.15°C

 Resolution
 0.1°C

Conductivity Sensor Type 4-electrode cell with autoranging

Range 0 to 200 mS/cm

Accuracy $\pm 0.5\%$ of reading or ± 0.001 mS/cm; whichever is greater (4-meter cable)

 \pm 1.0% of reading or \pm 0.001 mS/cm; whichever is greater (20-meter cable)

Resolution 0.001 mS/cm to 0.1 mS/cm (range-dependent)

Sensor Type Calculated from conductivity and temperature

Range 0 to 70 ppt Accuracy $\pm 1.0\%$ of reading or ± 0.1 ppt, whichever is greater

Resolution 0.01 ppt

pH (optional) Sensor Type Glass combination electrode

Range 0 to 14 units
Accuracy ±0.2 units
Resolution 0.01 units

ORP (optional) Sensor Type Platinum button
Range -999 to +999 mV

Range -999 to +999 mV Accuracy ± 20 mV Resolution 0.1 mV

Total Dissolved Solids Sensor Type Calculated from conductivity (variable constant, default 0.65)

(TDS) Range 0 to 100 g/L

Resolution 4 digits

Burometer (optional) Range 500 to 800 mm Hg
Accuracy ± 3 mm Hg within ± 10°C temperature range from calibration point

Resolution 0.1 mm Hg

YSI 556 Instrument Specifications

Size 11.9 cm width x 22.9 cm lenth (4.7 in. x 9 in.)

Weight with butteries 2.1 lbs. (916 grams)

Power 4 alkaline C-cells; optional rechargeable pack Cobles 4-, 10-, and 20-m (13.1, 32.8, 65.6 ft.) lengths Warronty 3-year instrument; 1-year probes and cables

Communication Port RS-232 Serial

Duta Logger 49,000 data sets, date and time stamp, manual or logging, with user-selectable intervals

556 Ordering Information (Order all items separately)

556-01 Instrument (with 5061 large, soft-sided carrying case)
556-02 Instrument with barometer option (with 5061 carrying case)

5563-4 4-m cable and DO/temp/conductivity 5563-10 10-m cable and DO/temp/conductivity 5563-20 20-m cable and DO/temp/conductivity

5564 pH Probe for any 5563 cable 5565 pH/ORP Probe for any 5563 cable

6118 Rechargeable battery pack kit (includes battery, adapter, charger)

614 Ultra clamp, C-clamp mount 616 Charger, cigarette lighter

4654 Tripod (small tripod for instrument)

5060 Small carrying case, soft-sided (fits instrument and 4-m cable)

5065 Form-fitted carrrier with shoulder strap

5080 Small carrying case, hard-sided (fits instrument, 4-m cable, flow

cell, batteries, membrane kit, calibration bottles)

5083 Flow cell

5085 Hands-free harness

5580 Confidence Solution[®] (insure probe accuracy with a simple field-


check for conductivity, pH, and ORP)



The 5080 carrying case with 556, 5563-4 cable, and 5083 flow cell.

YSI Environmental







YSI 556 MPSMulti Probe System

Operations Manual

Contents

1.	Safe	ety	1
	1.1	General Information	1
2.	Gen	neral Information	6
	2.1	Description	6
	2.2	Unpacking the Instrument	
	2.3	Features of the YSI 556 Multi-Probe System	
	2.4	Batteries	
	2.5	Power On	
	2.6	Setting Display Contrast	14
	2.7	Backlight	
	2.8	General Screen Features	15
	2.9	Keypad Use	16
	2.10	Instrument Reset	
	2.11	Menu Flowchart	18
3.	Pro	be Module	18
	3.1	Introduction	19
	3.2	Unpacking the Probe Module	
	3.3	Features of the YSI 5563 Probe Module	
	3.4	Preparing the Probe Module	
	3.5	Transport/Calibration Cup	
	3.6	Instrument/Cable Connection	
4.	Sen	sors	26
5.		oort	
6.	Cal	ibrate	
	6.1	Getting Ready to Calibrate	32
	6.2	Calibration Procedures	
	6.3	Return to Factory Settings.	52
7.	Rur	n	54
	7.1	Real-Time Data	54
8.	File	3	55
	8.1	Accessing the File Screen	
	8.2	Directory	
	8.3	View File	
	8.4	Upload to PC	
	8.5	File Memory	
	8.6	Delete All Files	

Contents

9.	Log	ging	66			
	9.1	Accessing the Logging Setup Screen	66			
	9.2	Setting Logging Interval				
	9.3	Storing Barometer Readings				
	9.4	Creating a Site List				
	9.5	Editing a Site List				
	9.6	Logging Data Without a Site List	72			
	9.7	Logging Data with a Site List	75			
9.8 Adding Data to Existing Files						
10	. Syst	tem Setup	79			
	10.1	Accessing the System Setup Screen	79			
	10.2	Language Setting				
	10.3	Date and Time Setup				
	10.4	Data Filter				
	10.5	Shutoff Time	84			
	10.6	Comma Radix	85			
	10.7	ID	85			
	10.8	GLP Filename	85			
	10.9	TDS Constant	86			
	10.10	Barometer Units	87			
	10.11	Calibrate Barometer	88			
11	. Mai	ntenance	90			
	11.1	Sensor Care and Maintenance	90			
	11.2	Upgrading YSI 556 MPS Software	96			
12	. Stor	rage	99			
	12.1	General Recommendations for Short Term Storage				
	12.2	General Recommendations for Long Term Storage				
13	. Tro	ubleshootingubleshooting				
14	. Ann	oendix A YSI 556 MPS Specifications	105			
15		pendix B Instrument Accessories				
16	. App	oendix C Required Federal Communications Notice	107			
17	17. Appendix D Health Safety108					
18	. App	oendix E Customer Service	111			
	18.1	Ordering and Technical Support	111			
	18.2	YSI Authorized Service Centers				
	18.3	Cleaning Instructions				
_		VOLETO MDO				

Contents

18.4	Packing Procedure	112
18.5	Warranty	113
19. App	endix F Ferrite Bead Installation	114
20. App	endix G EcoWatch	116
20.1	Installing EcoWatch for Windows	116
21. App	endix H Calibration Record Information	127
21.1	Viewing the Calibration Record (.glp) File	127
21.2	Uploading the Calibration Record (.glp) File	
21.3	Understanding the Calibration Record (.glp) File	

1. Safety

1.1 **General Information**

Read all safety information in this manual carefully before using the YSI 556 Multi-Probe System (MPS). Reagents that are used to calibrate and check this instrument may be hazardous to your health. Take a moment to review Appendix D Health and Safety.

⚠ WARNING

Warnings are used in this manual when misuse of the instrument could result in death or serious injury to a person.

riangle CAUTION

Cautions are used in this manual when misuse of the instrument could result in mild or serious injury to a person and/or damage to equipment.

riangle important safety instructions!

riangle save these instructions!



In essence, the most important safety rule for use of the YSI 556 MPS is to utilize the instrument ONLY for purposes documented in this manual. This is particularly true of the YSI 6117 rechargeable battery pack that contains nickel metal hydride (NiMH) batteries. The user should be certain to read all of the safety precautions outlined below before using the instrument.

/ Batteries

This instrument is powered by alkaline or optional nickel-metal hydride batteries, which the user must remove and dispose of when the batteries no longer power the instrument. Disposal requirements vary by country and region, and users are expected to understand and follow the battery disposal requirements for their specific locale.

The circuit board in this instrument contains a manganese dioxide lithium "coin cell" battery that must be in place for continuity of power to memory devices on the board. This battery is not user serviceable or replaceable.

YSI 556 MPS YSI Incorporated Page 1

When appropriate, an authorized YSI service center will remove this battery and properly dispose of it, per service and repair policies.

⚠YSI Rechargeable Battery Pack Safety Information

ARestrictions on Usage

- 1. Never dispose of the battery pack in a fire.
- 2. Do not attempt to disassemble the YSI 6117 battery pack
- 3. Do not tamper with any of the electronic components or the batteries within the battery pack. Tampering with either the electronic circuitry or the batteries will result in the voiding of the warranty and the compromising of the system performance, but, more importantly, can cause safety hazards which result from overcharging such as overheating, venting of gas, and loss of corrosive electrolyte.
- 4. Do not charge the battery pack outside the 0–40°C temperature range.
- 5. Do not use or store the battery at high temperature, such as in strong direct sunlight, in cars during hot weather, or directly in front of heaters.
- 6. Do not expose the battery pack to water or allow the terminals to become damp.
- 7. Avoid striking or dropping the battery pack. If the pack appears to have sustained damage from these actions or malfunctions after an impact or drop, the user should not attempt to repair the unit. Instead, contact YSI Customer Service. Refer to *Appendix E Customer Service*.
- 8. If the battery pack is removed from the YSI 556 MPS, do not store it in pockets or packaging where metallic objects such as keys can short between the positive and negative terminals.

Precautions for Users with Small Children.

Keep the battery pack out of reach of babies and small children.

Danger Notifications – Misuse creates a STRONG possibility of death or serious injury.

Page 2 YSI 556 MPS YSI Incorporated

FAILURE TO CAREFULLY OBSERVE THE FOLLOWING PROCEDURES AND PRECAUTIONS CAN RESULT IN LEAKAGE OF BATTERY FLUID, HEAT GENERATION, BURSTING, AND SERIOUS PERSONAL INJURY.

- 1. Never dispose of the battery pack in a fire or in heat.
- 2. Never allow the positive and negative terminals of the battery pack to become shorted or connected with electrically conductive materials. When the battery pack has been removed from the YSI 556 MPS, store it in a heavy plastic bag to prevent accidental shorting of the terminals.
- 3. Never disassemble the battery pack and do not tamper with any of the electronic components or the batteries within the battery pack. The battery pack is equipped with a variety of safety features. Accidental deactivation of any of these safety features can cause a serious hazard to the user.
- 4. The NiMH batteries in the battery pack contain a strong alkaline solution (electrolyte). The alkaline solution is extremely corrosive and will cause damage to skin or other tissues. If any fluid from the battery pack comes in contact with a user's eyes, immediately flush with clean water and consult a physician immediately. The alkaline solution can damage eyes and lead to permanent loss of eyesight.

Warning Notifications – Misuse creates a possibility of death or serious injury

- 1. Do not allow the battery pack to contact freshwater, seawater, or other oxidizing reagents that might cause rust and result in heat generation. If a battery becomes rusted, the gas release vent may no longer operate and this failure can result in bursting.
- 2. If electrolyte from the battery pack contacts the skin or clothing, thoroughly wash the area immediately with clean water. The battery fluid can irritate the skin.

Caution Notifications – Misuse creates a possibility of mild or serious injury or damage to the equipment.

1. Do not strike or drop the battery pack. If any impact damage to the battery pack is suspected, contact YSI Customer Service. Refer to *Appendix E Customer Service*.

YSI Incorporated YSI 556 MPS Page 3

- 2. Store the battery pack out of reach of babies and small children.
- 3. Store the battery pack between the temperatures of -20 and 30°C.

4. Before using the battery pack, be sure to read the operation manual and all precautions carefully. Then store this information carefully to use as a reference when the need arises.

⚠YSI 616 Cigarette Lighter Charger Safety Information

- 1. This section contains important safety and operating instructions for the YSI 556 MPS cigarette lighter battery charger (YSI 616; RadioShack Number 270-1533E). BE SURE TO SAVE THESE INSTRUCTIONS.
- 2. Before using the YSI 616 cigarette lighter charger, read all instructions and cautionary markings on battery charger, battery pack, and YSI 556 MPS.
- 3. Charge the YSI 6117 battery pack with the YSI 616 cigarette lighter charger ONLY when the YSI 6117 is installed in the YSI 556 MPS.
- 4. Do not expose charger to rain, moisture, or snow.
- 5. Use of an attachment not recommended or sold by the battery charger manufacturer may result in a risk of fire, electric shock, or injury to persons.
- 6. To reduce risk of damage to cigarette lighter and cord, pull by cigarette lighter rather than cord when disconnecting charger.
- 7. Make sure that the cord is located so that it will not be stepped on, tripped over, or otherwise subjected to damage or stress.
- 8. Do not operate charger with damaged cord or cigarette lighter connector replace it immediately.
- 9. Do not operate charger if it has received a sharp blow, been dropped, or otherwise damaged in any way; contact YSI Customer Service. Refer to *Appendix E Customer Service*.
- 10. Do not disassemble charger other than to change the fuse as instructed. Replace the part or send it to YSI Product Service if repair is required (refer to *Appendix E Customer Service*). Incorrect reassembly may result in a risk of electric shock or fire.

Page 4 YSI 556 MPS YSI Incorporated

11. To reduce risk of electric shock, unplug charger before attempting any maintenance or cleaning. Turning off controls will not reduce this risk.

⚠ YSI 556 MPS Water Leakage Safety Information

The YSI 556 MPS has been tested and shown to comply with IP67 criterion, i.e. submersion in 1 meter of water for 30 minutes with no leakage into either the battery compartment or the main case. However, if the instrument is submersed for periods of time in excess of 30 minutes, leakage may occur with subsequent damage to the batteries, the rechargeable battery pack circuitry, and/or the electronics in the main case.

If leakage into the battery compartment is observed when using alkaline C cells, remove batteries, dispose of batteries properly, and dry the battery compartment completely, ideally using compressed air. If corrosion is present on the battery terminals, contact YSI Customer Service for instructions. Refer to *Appendix E Customer Service*.

If leakage into the battery compartment is observed when using the YSI rechargeable battery pack, remove the battery assembly and set aside to dry. Return the battery pack to YSI Product Service for evaluation of possible damage. Finally dry the battery compartment completely, ideally using compressed air. If corrosion is present on the battery terminals, contact YSI Customer Service for instructions. Refer to Appendix E Customer Service.

CAUTION: If water has contacted the rechargeable battery pack, do not attempt to reuse it until it has been evaluated by YSI Product Service (refer to Appendix E Customer Service). Failure to follow this precaution can result in serious injury to the user.

If it is suspected that leakage into the main cavity of the case has occurred, remove the batteries immediately and return the instrument to YSI Product Service for damage assessment. Refer to *Appendix E Customer Service*.

CAUTION: Under no circumstances should the user attempt to open the main case.

YSI Incorporated YSI 556 MPS Page 5

2. General Information

2.1 Description

The rugged and reliable YSI 556 MPS (Multi-Probe System) combines the versatility of an easy-to-use, easy-to-read handheld unit with all the functionality of a multi-parameter system. Featuring a waterproof, impact-resistant case, the YSI 556 MPS simultaneously measures dissolved oxygen, conductivity, temperature, and optional pH and ORP. A simple cellular phone style keypad and large display make the instrument easy to use. The YSI 556 MPS is compatible with YSI EcoWatch for Windows software.

The YSI 556 MPS assists the user in conforming to Good Laboratory Practice (GLP) standards which help ensure that quality control/quality assurance methods are followed. Battery life is displayed with a fuel gauge, and the user can choose standard alkaline batteries or an optional rechargeable battery pack.

The 1.5 MB memory can store more than 49,000 data sets. Other options include a flow cell and barometer. The internal barometer can be user-calibrated and displayed along with other data, used in dissolved oxygen calibrations, and logged to memory for tracking changes in barometric pressure.

Features

- Waterproof -meets IP67 specifications
- Field-replaceable DO electrode module; pH and pH/ORP sensors
- Compatible with EcoWatch for Windows data analysis software
- Assists with Good Laboratory Practice Standards (GLP)
- Choice of DO membrane material for different applications
- Easy-to-use, screw-on cap DO membranes
- User-upgradeable software from YSI website
- Three-year warranty on the instrument; one-year on the probe modules
- Available with 4,10, and 20 m cable lengths
- Stores over 49,000 data sets, time and date stamped

Page 6 YSI 556 MPS YSI Incorporated

- Auto temperature compensating display contrast
- Optional barometer
- Optional rechargeable battery pack or standard alkaline batteries

2.2 Unpacking the Instrument

1. Remove the instrument from the shipping box. Note that the probe module and sensors are shipped in a separate box and will be unpacked later in Section 3.2 *Unpacking the Probe Module*

NOTE: Do not discard any parts of supplies.

- **2.** Use the packing list to ensure all items are present.
- **3.** Visually inspect all components for damage.

NOTE: If any parts are missing or damaged, contact your YSI Service Center immediately. Refer to Appendix E Customer Service or www.ysi.com.

YSI Incorporated YSI 556 MPS Page 7

2.3 Features of the YSI 556 Multi-Probe System




Figure 2.1 Front View of YSI 556 MPS




Figure 2.2 Back View of YSI 556 MPS

2.4 Batteries

2.4.1 Battery Life

Standard Alkaline Batteries

With the standard battery configuration of 4 alkaline C cells, the YSI 556 MPS will operate continuously for approximately 180 hours. Assuming a standard usage pattern when sampling of 3 hours of "on time" in a typical day, the alkaline cells will last approximately 60 days.

Optional Rechargeable Battery Pack

When fully charged, the optional rechargeable battery pack will provide approximately 50 hours of battery life.

YSI Incorporated YSI 556 MPS Page 9

2.4.2 Inserting 4 C Batteries




Figure 2.1 Inserting C Cells

CAUTION: Install batteries properly to avoid damage to the instrument.

- 1. Loosen the four screws in the battery lid on the back of the instrument using any screwdriver.
- 2. Remove the battery lid.
- 3. Insert four C batteries between the clips following the polarity (+ and -) labels on the bottom of the battery compartment.
- 4. Check gasket for proper placement on the battery lid.
- **5.** Replace the battery lid and tighten the 4 screws securely and evenly.

NOTE: Do not over-tighten the screws.

Page 10 YSI 556 MPS YSI Incorporated

2.4.3 Inserting Optional Rechargeable Battery Pack




Figure 2.2 Inserting Battery Pack

CAUTION: Read all cautions and warning that come with the battery pack before using the battery pack.

- 1. Loosen the four screws in the battery lid on the back of the instrument using any screwdriver.
- **2.** Remove the C battery lid and store for future use. Remove C batteries, if installed.
- **3.** Install the rechargeable battery pack and lid and tighten the 4 screws securely and evenly.

NOTE: Do not over tighten the screws.

YSI Incorporated YSI 556 MPS Page 11

2.4.4 Charging the Optional Rechargeable Battery Pack




Figure 2.3 Charging the Battery Pack

CAUTION: Do not use or store the battery pack at extreme temperatures such as in strong direct sunlight, in cars during hot weather or close to heaters.

- **1.** Install the rechargeable battery pack into the instrument as described in Section 2.4.3 Inserting Optional Rechargeable Battery Pack.
- **2.** Attach the charger adapter cable (YSI 6119) to the instrument.

NOTE: Wall power supplies for use in countries outside the US and Canada can be found in *Appendix B Instrument Accessories*.

3. Insert the barrel connector of the wall power supply into the barrel of the adapter cable.

CAUTION: Do not charge the battery pack continuously for more than 48 hours.

ACAUTION: Do not drop or expose to water.

CAUTION: Do no charge the battery pack at temperatures below 0°C or above 40°C.

4. Plug the wall power supply into an AC power outlet for approximately 2 hours to obtain an 80% to 90% charge for 6 hours to get a full charge.

Page 12 YSI 556 MPS YSI Incorporated

NOTE: The battery pack can be recharged whether the instrument is on or off.

2.4.5 Storing the Battery Pack

Remove the battery pack from the instrument when the instrument will not be used for extended periods of time to prevent over discharge of the battery pack.

Store the battery pack in a heavy plastic bag to prevent accidental shorting of the terminals. Store between -20 and 30°C.

2.4.6 Optional Cigarette Lighter Charger

AUTION: Read all warnings and cautions that come with the charger before using the charger.

CAUTION: Only use cigarette lighter charger when rechargeable battery pack is inserted into instrument.

CAUTION: Do not mishandle cigarette lighter charger. Do not expose to moisture.

- 1. Plug the barrel connector of the cigarette lighter charger into the mating end of the YSI 6119 Charger Adapter Cable.
- **2.** Attach the MS-19 end of the YSI 6119 Charger Adapter Cable to the instrument.
- **3.** Make one of the following modifications to the other end of the charger:

Slide the adapter ring off the plug to use the device with an American or Japanese vehicle.

American and Japanese Vehicles




Figure 2.1 Charger Plug Adapter Use

Leave the adapter ring on the plug and position it so that the slots on the adapter ring line up with the plug's spring clips to use the device on a European vehicle.

European Vehicles




Figure 2.2 European Charger Plug Adapter Use

NOTE: If the charger stops working properly, refer to Section 13 *Troubleshooting*.

2.5 Power On

Press and release the on/off button in the upper left corner of the instrument keypad to turn the instrument on or off. See Figure 2.1 Front View of YSI 556 MPS.

2.6 Setting Display Contrast

The display contrast automatically compensates for temperature changes. However, under extreme temperature conditions you may wish to optimize the display by manual adjustment as follows:

Page 14 YSI 556 MPS YSI Incorporated

1. Press and *hold down* the backlight key in the upper right corner of the keypad and press the "up" arrow to increase (darken) the contrast.

2. Press and *hold down* the backlight key in the upper right corner of the keypad and press the "down" arrow to decrease (lighten) the contrast.

2.7 Backlight

Press and *release* the backlight key in the upper right corner of the keypad to turn the backlight on or off. See Figure 2.1 Front View of YSI 556 MPS.

NOTE: The backlight turns off automatically after two minutes of non-use.




Figure 2.4 Main Screen Menu

2.9 Keypad Use




Figure 2.5 Keypad Features

KEY	LETTER/NUMBER
1	1
2	ABC2abc3
3	DEF3def3
4	GHI4ghi4
5	JKL5jkl5
6	MNO6mno6
7	PQRS7pqrs7
8	TUV8tuv8
9	WXYZ9wxyz9
0	0

Figure 2.6 Keypad Features

1. See Figure 2.10 Keypad Letters & Numbers and press the appropriate key repeatedly until letter or number desired appears in display.

NOTE: Press the key repeatedly in rapid succession to get to the desired letter or number. If you pause for more than a second, the cursor automatically scrolls to the right to prepare for the next input.

EXAMPLE 1: Press the 6 key *once* and *release* to display an uppercase "M".

EXAMPLE 2: Press the **6** key *four times* and *release* to display the number "6".

EXAMPLE 3: Press the 6 key *five times* and *stop* to display a lowercase "m".

2. Press the left arrow key to go back and reenter a number or setter that needs to be changed.


Press the **Enter** key when your entry is complete.

NOTE: The instrument software permits only numeric entries in many instances, such as when setting the clock or entering calibration parameters.

2.10 Instrument Reset

The YSI 556 MPS is characterized by sophisticated software that should provide trouble-free operation. However, as with all high-capability software packages, it is always possible that the user will encounter circumstances in which the instrument does not respond to keypad entry. If this occurs, the instrument function can easily be restored by removing and then reapplying battery power. Simply remove either your C-cells or rechargeable battery pack from the battery compartment, wait 30 seconds and then replace the batteries. See Section 2.4 Batteries for battery removal/reinstallation instructions.

2.11 Menu Flowchart



3. Probe Module

3.1 Introduction

The YSI 5563 Probe module is used for measuring dissolved oxygen, temperature, conductivity, and optional pH and ORP. The probe module is rugged, with the sensors enclosed in a heavy duty probe sensor guard with attached sinking weight. A 4, 10 or 20 meter cable is directly connected to the probe module body making it waterproof. An MS-19 connector at the end of the cable makes the YSI 5563 fully compatible with the YSI 556 Multi-Probe System.

3.2 Unpacking the Probe Module

1. Remove the YSI 5563 Probe Module from the shipping boxes.

NOTE: Do not discard any parts or supplies.

- 2. Use the packing list to ensure all items are present.
- **3.** Visually inspect all components for damage.

NOTE: If any parts are missing or damaged, contact a YSI representative immediately. Refer to: *Appendix E Customer Service* o visit www.ysi.com.

Page 19 YSI 556 MPS YSI Incorporated

3.3 Features of the YSI 5563 Probe Module




Figure 3.1 Probe Module

3.4 Preparing the Probe Module

To prepare the probe module for calibration and operation, you need to install the sensors into the connectors on the probe module bulkhead. In addition to sensor installation, you need to install a new DO membrane cap.

3.4.1 Sensor Installation

Whenever you install, remove or replace a sensor, it is extremely important that the entire probe module and all sensors be thoroughly dried prior to the removal of a sensor or a sensor port plug. This will prevent water from entering the port. Once you remove a sensor or plug, examine the connector inside the probe module sensor port. If any moisture is present, use compressed air to completely dry the connector. If the connector is corroded, return the probe module to your YSI Distributor or directly to YSI Customer Service. Refer to Appendix E Customer Service.

Page 20 YSI 556 MPS YSI Incorporated

Conductivity/Temperature and pH, pH/ORP Sensor Installation

- 1. Unscrew and remove the probe sensor guard.
- **2.** Using the sensor installation tool supplied in the YSI 5511 maintenance kit, unscrew and remove the sensor port plugs.




Figure 3.2 Port Plug Removal

3. Locate the port with the connector that corresponds to the sensor that is to be installed.




Figure 3.3 Sensor Port Identification

4. Apply a thin coat of o-ring lubricant (supplied in the YSI 5511 maintenance kit) to the o-rings on the connector side of the sensor (see Figure 3.4 O-ring Lubrication).




Figure 3.4 O-ring Lubrication

CAUTION: Make sure that there are NO contaminants between the o-ring and the sensor. Contaminants that are present under the o-ring may cause the o-ring to leak.

- **5.** Be sure the probe module sensor port is free of moisture and then insert the sensor into the correct port. Gently rotate the sensor until the two connectors align.
- **6.** With the connectors aligned, screw down the sensor nut using the sensor installation tool.




Figure 3.5 Sensor Installation

CAUTION: Do not cross thread the sensor nut. Tighten the nut until it is flush with the face of the probe module bulkhead. Do not over tighten.




Figure 3.6 Bulkhead Seating

7. Repeat steps 3-6 for any other sensors.

Page 22

YSI 556 MPS

YSI Incorporated

8. Replace the probe sensor guard.

Dissolved Oxygen Sensor Installation

The YSI 5563 comes with the DO sensor already installed. Refer to Section 11.1.2 DO Sensor Replacement for instructions on installing the YSI 559 Replaceable DO Module Kit.

3.4.2 Membrane Cap Selection

The YSI 5563 is shipped with a YSI 5909 kit that contains membrane caps made with 2 mil polyethylene (PE), a material which should be ideal for most field applications of the 556. However, YSI also offers membrane caps made with two other materials (1 mil polyethylene and 1 mil Teflon) which some users may also prefer. All membranes available for the 556/5563 system provide comparable accuracy if used properly. The difference between the two thicknesses of PE is found in the trade-off of flow dependence and response time as described below. Teflon is offered because some users may prefer to continue using the traditional membrane material used by YSI. To avoid confusion, the membrane caps are color coded as described below and can be ordered in kits as noted:

```
1 mil Teflon – Black Caps (Kit = YSI 5906)
1 mil Polyethylene (PE) – Yellow Caps (Kit = YSI 5908)
2 mil Polyethylene (PE) – Blue Caps (Kit = YSI 5909)
```

The 1 mil Teflon caps will offer traditional, reliable performance for most dissolved oxygen applications. The 1 mil PE caps will provide a significantly faster dissolved oxygen response (as long as your 556 Data Filter is set correctly as described below in Sections 10.2 and 10.3.1) while also giving readings which are significantly less flow dependent than the 1 mil Teflon caps. Finally, 2 mil PE caps will show a large reduction in flow dependence over 1 mil Teflon while not significantly increasing the response time. Generally, one of the PE caps is likely to provide better performance for your application.

IMPORTANT: No matter which type of membrane cap you select, you will have to confirm your selection in the 556 software from the Sensor menu as described in Section 4 Sensors.

3.4.3 Membrane Cap Installation

NOTE: The YSI 5563 DO sensor (already installed in the probe module) was shipped dry. A shipping membrane was installed to protect the electrode. A new membrane cap must be installed before the first use.

- 1. Unscrew and remove the probe sensor guard.
- **2.** Unscrew, remove, and discard the old membrane cap.
- **3.** Thoroughly rinse the sensor tip with distilled water.
- **4.** Prepare the electrolyte according to the directions on the electrolyte solution bottle.
- **5.** Hold the new membrane cap and fill it at least ½ full with the electrolyte solution.
- **6.** Screw the membrane cap onto the sensor moderately tight. A small amount of electrolyte should overflow.
- **Caution:** Do not touch the membrane surface.
 - 7. Screw the probe sensor guard on moderately tight.

3.5 Transport/Calibration Cup

The YSI 5563 Probe module has been supplied with a convenient transport/calibration cup. This cup is an ideal container for calibration of the different sensors, minimizing the amount of solution needed. Refer to Section 6 Calibrate.

Page 24 YSI 556 MPS YSI Incorporated

3.5.1 Transport/Calibration Cup Installation

- 1. Remove probe sensor guard, if already installed.
- **2.** Ensure that an o-ring is installed in the o-ring groove on the threaded end of the probe module body.
- **3.** Screw the transport/calibration cup on the threaded end of the probe module and securely tighten.

NOTE: Do not over tighten as this could cause damage to the threaded portions.




Figure 3.7 Transport/Calibration Cup Installation

3.6 Instrument/Cable Connection

Attach the cable to the instrument as follows:

- 1. Line up the pins and guides on the cable with the holes and indentations on the cable connector at the bottom of the YSI 556 instrument. See Figure 2.1 Front View of YSI 556 MPS.
- **2.** Holding the cable firmly against the cable connector, turn the locking mechanism clockwise until it snaps into place.

Remove the cable from the instrument by turning the cable connector counterclockwise until the cable disengages from the instrument.

4. Sensors

The Sensors screen allows the user to enable or disable each of the sensors and select which membrane material will be used for the dissolved oxygen sensor. Disabled sensors will not be displayed on the screen in real time or logged to files.

- 1. Press the On/off key to display the run screen.
- 2. Press the Escape key to display the main menu screen.





Figure 4.1 Main Menu Screen

- **3.** Use the arrow keys to highlight the **Sensor** selection.
- 4. Press the Enter key to display the sensors enabled screen.



YSI 556 MPS

YSI Incorporated

Sensors Section 4

Figure 4.2 Sensors Enabled Screen Before DO Membrane Selection

A black dot to the left of a sensor indicates that sensor is enabled. Sensors with an empty circle are disabled.

Highlight the "DO None" entry as shown above and press **Enter** to display the membrane choice screen. Consult Section 3.4.2 Membrane Cap Selection for information on the advantages of each type of membrane material. Blue membrane caps using 2 mil polyethylene (PE) were shipped with your YSI 5563 and are likely to be the best choice for most 556 field applications.




Figure 4.3 Membrane Selection Screen

Highlight the desired membrane choice — in this case, 2 mil PE - and press Enter to activate your selection with a dot to the left of the screen. Then press **Escape** to return to the Sensor menu that now shows your DO membrane selection.




Figure 4.4 Sensors Enabled Screen After DO Membrane Selection

NOTE: The Temperature sensor cannot be disabled. Most other sensors require temperature compensation for accurate readings. In addition, the conductivity sensor must be activated in order to obtain accurate dissolved oxygen mg/L readings.

- **5.** Use the arrow keys to highlight the sensor you want to change, then press the Enter key to enable or disable it.
- **6.** Repeat step 5 for each sensor you want to change.
- 7. Press the Escape key to return to the main menu screen.

Page 28 YSI 556 MPS YSI Incorporated

5. Report

The Report Setup screen allows the user to select which sample parameters and units the YSI 556 MPS will display on the screen. It does NOT determine which parameters are logged to memory. Refer to Section 4 Sensors.

- 1. Press the On/off key to display the run screen.
- 2. Press the Escape key to display the main menu screen.





Figure 5.1 Main Menu

- **3.** Use the arrow keys to highlight the **Report** selection.
- **4.** Press the **Enter** key to display the report setup screen.



YSI 556 MPS

YSI Incorporated

Report Section 5

Figure 5.2 Report Setup Screen

NOTE: A black dot to the left of a parameter indicates that parameter is selected for display. Parameters with an empty circle will not be displayed.

NOTE: You may have to scroll down past the bottom of the screen to see all the parameters.

- **5.** Use the arrow keys to highlight the parameter you want to change, then press the **Enter** key. If you can't find the parameter you want, even after scrolling down past the bottom of the screen, the sensor used for that parameter is disabled. Refer to Section 4 Sensors.
- **6.** If you selected Temperature, Specific Conductivity, Conductivity, Resistance or Total Dissolved Solids, the Units screen will appear.




Figure 5.3 Units Screen

- 7. Use the arrow keys to select the units desired, then press the **Enter** key to return to the report setup screen.
- **8.** Repeat steps 5 and 6 for each parameter you want to change.

Page 30 YSI 556 MPS YSI Incorporated

Report Section 5

NOTE: Specific Conductance (temperature compensated conductivity) is notated on the Run screen with a small 'c' after the units of measure.

All parameters may be enabled at the same time.




Figure 5.4 All Parameters Displayed

9. Press the **Escape** key to return to the Main menu screen.

6. Calibrate

All of the sensors, except temperature, require periodic calibration to assure high performance. You will find specific calibration procedures for all sensors that require calibration in the following sections. If a sensor listed is not installed in your probe module, skip that section and proceed to the next sensor until the calibration is complete.



CAUTION: Reagents that are used to calibrate and check this instrument may be hazardous to your health. Take a moment to review Appendix D Health and Safety. Some calibration standard solutions may require special handling.

6.1 **Getting Ready to Calibrate**

6.1.1 Containers Needed to Calibrate the Probe Module

The transport/calibration cup that comes with your probe module serves as a calibration chamber for all calibrations and minimizes the volume of calibration reagents required.

Instead of the transport/calibration cup, you may use laboratory glassware to perform calibrations. If you do not use the transport/calibration cup that is designed for the probe module, you are cautioned to do the following:

- Perform all calibrations with the Probe Sensor Guard installed. This protects the sensors from possible physical damage.
- ✓ Use a ring stand and clamp to secure the probe module body to prevent the module from falling over. Most laboratory glassware has convex bottoms.
- Ensure that all sensors are immersed in calibration solutions. Many of the calibrations factor in readings from other sensors (e.g., temperature sensor). The top vent hole of the conductivity sensor must also be immersed during some calibrations.

Page 32 YSI 556 MPS YSI Incorporated Calibrate Section 6

6.1.2 Calibration Tips

1. If you use the Transport/Calibration Cup for dissolved oxygen (DO) calibration, make certain to loosen the seal to allow pressure equilibration before calibration. The DO calibration is a water-saturated air calibration.

- **2.** When calibrating pH, always calibrate with buffer 7 first, regardless if performing a 1, 2, or 3 point calibration
- **3.** The key to successful calibration is to ensure that the sensors are completely submersed when calibration values are entered. Use recommended volumes when performing calibrations.
- **4.** For maximum accuracy, use a small amount of previously used calibration solution to pre-rinse the probe module. You may wish to save old calibration standards for this purpose.
- **5.** Fill a bucket with ambient temperature water to rinse the probe module between calibration solutions.
- 6. Have several clean, absorbent paper towels or cotton cloths available to dry the probe module between rinses and calibration solutions. Shake the excess rinse water off of the probe module, especially when the probe sensor guard is installed. Dry off the outside of the probe module and probe sensor guard. Making sure that the probe module is dry reduces carry-over contamination of calibrator solutions and increases the accuracy of the calibration.
- 7. If you are using laboratory glassware for calibration, you do not need to remove the probe sensor guard to rinse and dry the sensors between calibration solutions. The inaccuracy resulting from simply rinsing the sensor compartment and drying the outside of the guard is minimal.
- 8. If you are using laboratory glassware, remove the stainless steel weight from the bottom of the probe sensor guard by turning the weight counterclockwise. When the weight is removed, the calibration solutions have access to the sensors

Section 6 Calibrate

without displacing a lot of fluid. This also reduces the amount of liquid that is carried between calibrations.

9. Make certain that port plugs are installed in all ports where sensors are not installed. It is extremely important to keep these electrical connectors dry.

6.1.3 Recommended Volumes

Follow these instructions to use the transport/calibration cup for calibration procedures.

✓ Ensure that an o-ring is installed in the o-ring groove of the transport/calibration cup bottom cap, and that the bottom cap is securely tightened.

NOTE: Do not over-tighten as this could cause damage to the threaded portions.

- ✓ Remove the probe sensor guard, if it is installed.
- ✓ Remove the o-ring, if installed, from the probe module and inspect the installed o-ring on the probe module for obvious defects and, if necessary, replace it with the extra o-ring supplied.
- ✓ Some calibrations can be accomplished with the probe module upright or upside down. A separate clamp and stand, such as a ring stand, is required to support the probe module in the upside down position.
- ✓ To calibrate, follow the procedures in the next section, Calibration Procedures. The approximate volumes of the reagents are specified below for both the upright and upside down orientations.
- ✓ When using the Transport/Calibration Cup for dissolved oxygen % saturation calibration, make certain that the vessel is vented to the atmosphere by loosening the bottom cap or cup assembly and that approximately 1/8 inch (3 cm) of water is present in the cup.

Page 34 YSI 556 MPS YSI Incorporated

Sensor to Calibrate	Upright	Upside Down
Conductivity	55ml	55ml
pH/ORP	30ml	60ml

Table 6.1 Calibration Volumes

6.2 Calibration Procedures

6.2.1 Accessing the Calibrate Screen

- 1. Press the On/off key to display the run screen.
- 2. Press the Escape key to display the main menu screen.
- **3.** Use the arrow keys to highlight the **Calibrate** selection.




Figure 6.1 Main Menu

4. Press the Enter key. The Calibrate screen will be displayed.




Figure 6.2 Calibrate Screen

6.2.2 Conductivity Calibration

This procedure calibrates specific conductance (recommended), conductivity and salinity. Calibrating any one option automatically calibrates the other two.

- **1.** Go to the calibrate screen as described in Section 6.2.1Accessing the Calibrate Screen.
- **2.** Use the arrow keys to highlight the **Conductivity** selection. See Figure 6.2 Calibrate Screen.
- **3.** Press **Enter**. The Conductivity Calibration Screen is displayed.

Page 36 YSI 556 MPS YSI Incorporated




Figure 6.3 Conductivity Calibration Selection Screen

- **4.** Use the arrow keys to highlight the Specific Conductance selection.
- **5.** Press **Enter**. The Conductivity Calibration Entry Screen is displayed.




Figure 6.4 Conductivity Calibration Selection Screen

6. Place the correct amount of conductivity standard (see Table 6.1 Calibration Volumes) into a clean, dry or pre-rinsed transport/calibration cup.

YSI Incorporated

YSI 556 MPS

Page 37

Section 6 Calibrate

WARNING: Calibration reagents may be hazardous to your health. See Appendix D Health and Safety for more information.

NOTE: For maximum accuracy, the conductivity standard you choose should be within the same conductivity range as the samples you are preparing to measure. However, we do not recommend using standards less than 1 mS/cm. For example:

- ✓ For fresh water use a 1 mS/cm conductivity standard.
- ✓ For brackish water use a 10 mS/cm conductivity standard.
- ✓ For seawater use a 50 mS/cm conductivity standard.

NOTE: Before proceeding, ensure that the sensor is as dry as possible. Ideally, rinse the conductivity sensor with a small amount of standard that can be discarded. Be certain that you avoid cross-contamination of solutions. Make certain that there are no salt deposits around the oxygen and pH/ORP sensors, particularly if you are employing standards of low conductivity.

- 7. Carefully immerse the sensor end of the probe module into the solution.
- **8.** Gently rotate and/or move the probe module up and down to remove any bubbles from the conductivity cell.

NOTE: The sensor must be completely immersed past its vent hole. Using the recommended volumes from Table 6.1 Calibration Volumes, should ensure that the vent hole is covered.

9. Screw the transport/calibration cup on the threaded end of the probe module and securely tighten.

NOTE: Do not over tighten as this could cause damage to the threaded portions.

Calibrate Section 6

10. Use the keypad to enter the calibration value of the standard you are using.

NOTE: Be sure to enter the value in mS/cm at 25°C.

11. Press **Enter**. The Conductivity Calibration Screen is displayed.




Figure 6.5 Conductivity Calibration Screen

- **12.** Allow at least one minute for temperature equilibration before proceeding. The current values of all enabled sensors will appear on the screen and will change with time as they stabilize.
- **13.** Observe the reading under Specific Conductance. When the reading shows no significant change for approximately 30 seconds, press **Enter**. The screen will indicate that the calibration has been accepted and prompt you to press **Enter** again to Continue.

Section 6 Calibrate




Figure 6.6 Calibrated

- **14.** Press **Enter**. This returns you to the Conductivity Calibrate Selection Screen, See Figure 6.3 Conductivity Calibration Selection Screen..
- **15.** Press **Escape** to return to the calibrate menu. See Figure 6.2 Calibrate Screen .
- **16.** Rinse the probe module and sensors in tap or purified water and dry.

6.2.3 Dissolved Oxygen Calibration

This procedure calibrates dissolved oxygen. Calibrating any one option (% or mg/L) automatically calibrates the other.

1. Go to the calibrate screen as described in Section 6.2.1 Accessing the Calibrate Screen.

NOTE: The instrument must be on for at least 10 - 15 minutes to polarize the DO sensor before calibrating.

- **2.** Use the arrow keys to highlight the **Dissolved Oxygen** selection. See Figure 6.2 Calibrate Screen.
- **3.** Press Enter. The dissolved oxygen calibration screen is displayed.

Page 40 YSI 556 MPS YSI Incorporated




Figure 6.7 DO Calibration Screen

DO Calibration in % Saturation

- 1. Use the arrow keys to highlight the DO% selection.
- **2.** Press Enter. The DO Barometric Pressure Entry Screen is displayed.




Figure 6.8 DO Barometric Pressure Entry Screen

- **3.** Place approximately 3 mm (1/8 inch) of water in the bottom of the transport/calibration cup.
- 4. Place the probe module into the transport/calibration cup.

YSI Incorporated

YSI 556 MPS

Section 6 Calibrate

NOTE: Make sure that the DO and temperature sensors are **not** immersed in the water.

- **5.** Engage only 1 or 2 threads of the transport/calibration cup to ensure the DO sensor is vented to the atmosphere.
- **6.** Use the keypad to enter the current local barometric pressure.

NOTE: If the unit has the optional barometer, no entry is required.

NOTE: Barometer readings that appear in meteorological reports are generally corrected to sea level and must be uncorrected before use (refer to Section 10.10 Calibrate Barometer, Step 2).

7. Press Enter. The DO% saturation calibration screen is displayed.




Figure 6.9 DO Sat Calibration Screen

8. Allow approximately ten minutes for the air in the transport/calibration cup to become water saturated and for the temperature to equilibrate before proceeding.

Page 42 YSI 556 MPS YSI Incorporated

Calibrate Section 6

9. Observe the reading under DO %. When the reading shows no significant change for approximately 30 seconds, press **Enter**. The screen will indicate that the calibration has been accepted and prompt you to press **Enter** again to Continue. See Figure 6.6 Calibrated.

- **10.** Press Enter. This returns you to the DO calibration screen, See Figure 6.7 DO Calibration Screen.
- **11.** Press **Escape** to return to the calibrate menu. See Figure 6.2 Calibrate Screen.
- **12.** Rinse the probe module and sensors in tap or purified water and dry.

DO Calibration in mg/L

DO calibration in mg/L is carried out in a water sample which has a known concentration of dissolved oxygen (usually determined by a Winkler titration).

- **1.** Go to the DO calibrate screen as described in Section 6.2.3 Dissolved Oxygen Calibration, steps 1 through 3.
- 2. Use the arrow keys to highlight the **DO mg/L** selection.
- **3.** Press Enter. The DO mg/L Entry Screen is displayed.




Figure 6.10 DO mg/L Entry Screen

4. Place the probe module in water with a known DO concentration.

NOTE: Be sure to completely immerse all the sensors.

- **5.** Use the keypad to enter the known DO concentration of the water.
- **6.** Press **Enter**. The Dissolved Oxygen mg/L Calibration Screen is displayed.




Figure 6.11 DO mg/L Calibration Screen

Calibrate Section 6

7. Stir the water with a stir bar, or by rapidly moving the probe module, to provide fresh sample to the DO sensor.

- **8.** Allow at least one minute for temperature equilibration before proceeding. The current values of all enabled sensors will appear on the screen and will change with time as they stabilize.
- **9.** Observe the DO mg/L reading, when the reading is stable (shows no significant change for approximately 30 seconds), press **Enter**. The screen will indicate that the calibration has been accepted and prompt you to press **Enter** again to Continue.
- **10.** Press **Enter**. This returns you to the DO calibration screen. See Figure 6.7 DO Calibration Screen.
- **11.** Press **Escape** to return to the calibrate menu. See Figure 6.2 Calibrate Screen.
- **12.** Rinse the probe module and sensors in tap or purified water and dry.

6.2.4 pH Calibration

- **1.** Go to the calibrate screen as described in Section 6.2.1 Accessing the Calibrate Screen.
- **2.** Use the arrow keys to highlight the **pH** selection. See Figure 6.2 Calibrate Screen.
- **3.** Press Enter. The pH calibration screen is displayed.

Section 6 Calibrate




Figure 6.12 pH Calibration Screen

- Select the **1-point** option only if you are adjusting a previous calibration. If a 2-point or 3-point calibration has been performed previously, you can adjust the calibration by carrying out a one point calibration. The procedure for this calibration is the same as for a 2-point calibration, but the software will prompt you to select only one pH buffer.
- Select the **2-point** option to calibrate the pH sensor using only two calibration standards. Use this option if the media being monitored is known to be either basic or acidic. For example, if the pH of a pond is known to vary between 5.5 and 7, a two-point calibration with pH 7 and pH 4 buffers is sufficient. A three point calibration with an additional pH 10 buffer will not increase the accuracy of this measurement since the pH is not within this higher range.
- Select the **3-point** option to calibrate the pH sensor using three calibration solutions. In this procedure, the pH sensor is calibrated with a pH 7 buffer and two additional buffers. The 3-point calibration method assures maximum accuracy when the pH of the media to be monitored cannot be anticipated. The procedure for this calibration is the same as for a 2-point calibration, but the software will prompt you to select a third pH buffer.
 - **4.** Use the arrow keys to highlight the **2-point** selection.

Page 46 YSI 556 MPS YSI Incorporated

Calibrate Section 6

5. Press Enter. The pH Entry Screen is displayed.




Figure 6.13 pH Entry Screen

6. Place the correct amount (see Table 6.1 Calibration Volumes) of pH buffer into a clean, dry or pre-rinsed transport/calibration cup.

NOTE: Always calibrate with buffer 7 first, regardless if performing a 1, 2, or 3 point calibration.



WARNING: Calibration reagents may be hazardous to your health. See Appendix D Health and Safety for more information.

NOTE: For maximum accuracy, the pH buffers you choose should be within the same pH range as the water you are preparing to sample.

NOTE: Before proceeding, ensure that the sensor is as dry as possible. Ideally, rinse the pH sensor with a small amount of buffer that can be discarded. Be certain that you avoid crosscontamination of buffers with other solutions.

- 7. Carefully immerse the sensor end of the probe module into the solution.
- 8. Gently rotate and/or move the probe module up and down to remove any bubbles from the pH sensor.

Section 6 Calibrate

NOTE: The sensor must be completely immersed. Using the recommended volumes from Table 6.1 Calibration Volumes, should ensure that the sensor is covered.

9. Screw the transport/calibration cup on the threaded end of the probe module and securely tighten

NOTE: Do not over tighten as this could cause damage to the threaded portions.

10. Use the keypad to enter the calibration value of the buffer you are using at the current temperature.

NOTE: pH vs. temperature values are printed on the labels of all YSI pH buffers.

11. Press Enter. The pH calibration screen is displayed.




Figure 6.14 pH Calibration Screen

- **12.** Allow at least one minute for temperature equilibration before proceeding. The current values of all enabled sensors will appear on the screen and will change with time as they stabilize.
- **13.** Observe the reading under pH, when the reading shows no significant change for approximately 30 seconds, press **Enter**.

Page 48

Calibrate Section 6

The screen will indicate that the calibration has been accepted and prompt you to press **Enter** again to Continue.

- **14.** Press **Enter**. This returns you to the specified pH Calibration Screen, See Figure 6.13 pH Entry Screen.
- **15.** Rinse the probe module, transport/calibration cup and sensors in tap or purified water and dry.
- **16.** Repeat steps 6 through 13 above using a second pH buffer.
- **17.** Press **Enter**. This returns you to the pH Calibration Screen, See Figure 6.12 pH Calibration Screen.
- **18.** Press **Escape** to return to the calibrate menu. See Figure 6.2 Calibrate Screen.
- **19.** Rinse the probe module and sensors in tap or purified water and dry.

6.2.5 ORP Calibration

- **1.** Go to the calibrate screen as described in Section 6.2.1 Accessing the Calibrate Screen.
- **2.** Use the arrow keys to highlight the **ORP** selection. See Figure 6.2 Calibrate Screen..
- **3.** Press Enter. The ORP calibration screen is displayed.

Section 6 Calibrate




Figure 6.15 Specified ORP Calibration Screen

4. Place the correct amount (see Table 6.1 Calibration Volumes) of a known ORP solution (we recommend Zobell solution) into a clean, dry or pre-rinsed transport/calibration cup.

WARNING: Calibration reagents may be hazardous to your health. See *Appendix D Health and Safety* for more information.

NOTE: Before proceeding, ensure that the sensor is as dry as possible. Ideally, rinse the ORP sensor with a small amount of solution that can be discarded. Be certain that you avoid cross-contamination with other solutions.

- **5.** Carefully immerse the sensor end of the probe module into the solution.
- **6.** Gently rotate and/or move the probe module up and down to remove any bubbles from the ORP sensor.

NOTE: The sensor must be completely immersed. Using the recommended volumes from Table 6.1 Calibration Volumes should ensure that the sensor is covered.

7. Screw the transport/calibration cup on the threaded end of the probe module and securely tighten.

NOTE: Do not over tighten as this could cause damage to the threaded portions.

YSI 556 MPS

YSI Incorporated

Calibrate Section 6

8. Use the keypad to enter the correct value of the calibration solution you are using at the current temperature. Refer to Table 6.2 Zobell Solution Values.

Temperature °C	Zobell Solution Value, mV	
-5	270.0	
0	263.5	
5	257.0	
10	250.5	
15	244.0	
20	237.5	
25	231.0	
30	224.5	
35	218.0	
40	211.5	
45	205.0	
50	198.5	

Table 6.2 Zobell Solution Values

9. Press **Enter**. The ORP calibration screen is displayed.




Figure 6.16 DO Cal Screen

10. Allow at least one minute for temperature equilibration before proceeding. The current values of all enabled sensors will appear on the screen and will change with time as they stabilize.

NOTE: Verify that the temperature reading matches the value you used in Table 6.2 Zobell Solution Values.

YSI Incorporated YSI 556 MPS Page 51

Section 6 Calibrate

11. Observe the reading under ORP, when the reading shows no significant change for approximately 30 seconds, press Enter. The screen will indicate that the calibration has been accepted and prompt you to press Enter again to Continue.

- **12.** Press **Enter**. This returns you to the Calibrate Screen. See Figure 6.2 Calibrate Screen.
- **13.** Rinse the probe module and sensors in tap or purified water and dry.

6.3 Return to Factory Settings.

- **1.** Go to the calibrate screen as described in Section 6.2.1 Accessing the Calibrate Screen.
- **2.** Use the arrow keys to highlight the **Conductivity** selection. See Figure 6.2 Calibrate Screen.

NOTE: We will use the Conductivity sensor as an example; however, this process will work for any sensor.

- **3.** Press **Enter.** The Conductivity Calibration Selection Screen is displayed. See Figure 6.3 Conductivity Calibration Selection Screen.
- **4.** Use the arrow keys to highlight the **Specific Conductance** selection.
- **5.** Press **Enter.** The Conductivity Calibration Entry Screen is displayed. See Figure 6.4 Conductivity Calibration Entry Screen.
- 6. Press and hold the Enter key down and press the Escape key.

Page 52 YSI 556 MPS YSI Incorporated

Calibrate Section 6




Figure 6.17 ORP Calibration Screen

7. Use the arrow keys to highlight the YES selection.

CAUTION: This returns a sensor to the factory settings. For example, in selecting to return specific conductance to the factory setting, salinity and conductivity will automatically return to their factory settings.

- **8.** Press **Enter**. This returns you to the Conductivity Calibrate Selection Screen, See Figure 6.3 Conductivity Calibration Selection Screen.
- **9.** Press **Escape** to return to the calibrate menu. See Figure 6.2 Calibrate Screen.

YSI Incorporated YSI 556 MPS Page 53

The Run screen displays data from the sensors in real-time and allows the user to log sample data to memory for later analysis. Refer to Section 9 Logging for details on logging sample data.

7.1 Real-Time Data

NOTE: Before measuring samples you must prepare the probe module (refer to Section 3.4 Preparing the Probe Module), attach the probe module to the instrument (refer to Section 3.6 Instrument/Cable Connection) and calibrate the sensors (refer to Section 6 Calibrate).

1. Press the On/off key.

OR select Run from the main menu to display the run screen.




Figure 7.1 Run Screen

- **2.** Make sure the probe sensor guard is installed.
- **3.** Place the probe module in the sample. Be sure to completely immerse all the sensors.
- **4.** Rapidly move the probe module through the sample to provide fresh sample to the DO sensor.
- **5.** Watch the readings on the display until they are stable.
- **6.** Refer to Section *9 Logging* for instructions on logging sample data.

Page 54 YSI 556 MPS YSI Incorporated

8. File

The File menu allows the user to view, upload or delete sample data and calibration record files stored in the YSI 556 MPS.

8.1 Accessing the File Screen

- 1. Press the On/off key to display the run screen.
- 2. Press the Escape key to display the main menu screen.




Figure 8.1 Main Menu Screen

- 3. Use the arrow keys to highlight the File selection.
- 4. Press the Enter key. The file screen is displayed.




Figure 8.2 File Screen

8.2 Directory

- **1.** Go to the file screen as described in Section 8.1 Accessing the File Screen.
- **2.** Use the arrow keys to highlight the **Directory** selection. See Figure 8.2 File Screen.
- 3. Press the Enter key. The file list screen is displayed.

NOTE: Files are listed in the order in which they are logged to memory. Sample Data files have the file extension .dat, while Calibration Record files have the file extension .glp.

Page 56 YSI 556 MPS YSI Incorporated

Filename	Samples	Bytes
RED.dat	26	955
CAT.dat	63	2028
OHIO.dat	118	3623
00008004.gl	6	130
01/20/2001 13:57:	736.8mmHg	

Figure 8.3 File List Screen

- 4. Use the arrow keys to highlight a file.
- **5.** Press the **Enter** key. The file details screen is displayed.




Figure 8.4 File Details Screen

- **6.** Press the **Enter** key to view the file data. Refer to Section 8.3 View File for details.
- 7. Press the Escape key repeatedly to return to the main menu screen.

YSI Incorporated YSI 556 MPS Page 57

8.3 View File

- **1.** Go to the file screen as described in Section 8.1 Accessing the File Screen. See Figure 8.2 File Screen.
- 2. Use the arrow keys to highlight the View file selection.
- **3.** Press the **Enter** key. A list of files is displayed. See Figure 8.3 File List Screen.
- **4.** Use the arrow keys to highlight an individual file.

NOTE: You may have to scroll down to see all the files.

5. Press the Enter key. The file data is displayed with the file name at t8e top of the display.

NOTE: If no file name was specified, the data is stored under the default name NONAME1.dat.

OHIO.dat				
Date	Time	Temp 🛊		
m/d/y	hh:mm:ss	ĊŢ		
01/20/2001	13:56:13	22.54		
01/20/2001	13:56:13	22.54		
,,,	13:56:14	22.54		
1,,	13:56:14			
	13:56:15	22.54		
,,	13:56:15			
	13:56:16	22.54		
,,	13:56:16	1 — — 1		
01/20/2001	13:56:17	22.54		
736.7mmHg				
01/20/2001 13:59:34				

Figure 8.5 File Data Screen

- **6.** Use the arrow keys to scroll horizontally and/or vertically to view all the data.
- **7.** Press the **Escape** key repeatedly to return to the main menu screen.

File Section 8

8.4 Upload to PC

EcoWatchTM for WindowsTM must be used as the PC software interface to the YSI 556 MPS. Refer to *Appendix G EcoWatch* for more information. EcoWatch for Windows® is available at no cost via a download from the YSI Web Site (www.ysi.com) or by contacting YSI Customer Support. Refer to *Appendix E Customer Service*.

8.4.1 Upload Setup

- **1.** Disconnect the YSI 5563 Probe Module from the YSI 556 MPS instrument.
- 2. Connect the YSI 556 MPS to a serial (Comm) port of your computer via the 655173 PC Interface cable as shown in the following diagram:




Figure 8.2 Computer/Instrument Interface


3. Open EcoWatch for Windows on your computer.

NOTE: See *Appendix G EcoWatch* for installation instructions.

4. Click on the sonde/probe icon in the upper toolbar.

YSI Incorporated YSI 556 MPS Page 59

5. Set the Comm port number to match the port the YSI 556 MPS is connected to. After this setup procedure, the following screen will be present on your PC monitor:



8.4.2 Uploading a .DAT File

- **1.** Setup the instrument as described in Section 8.4.1 Upload Setup.
- **2.** Go to the YSI 556 MPS file screen as described in Section 8.1 Accessing the File Screen.
- **3.** Use the arrow keys to highlight the **Upload to PC** selection. See Figure 8.2 File Screen.
- **4.** Press the **Enter** key. The file list screen is displayed. See Figure 8.3 File List Screen.
- 5. Use the arrow keys to highlight the DAT file that you wish to transfer and press Enter, both the YSI 556 MPS and PC displays show the progress of the file transfer.

File Section 8





Figure 8.3 File Transfer Progress Screen

NOTE: After transfer, the file will be located in the C:\ECOWWIN\DATA folder of your PC, designated with a .DAT extension.

6. After the file transfer is complete, close the terminal window (small window on the PC) by clicking on the "X" at its upper right corner.



7. Press the Escape key on the YSI 556 MPS repeatedly to return

Page 61 YSI Incorporated YSI 556 MPS

to the main menu screen.

8.4.3 Uploading a Calibration Record (.glp) File

For more information on the calibration record, refer to *Appendix H Calibration Record Information*.

- **1.** Setup up the instrument as described in Section 8.4.1 Upload Setup.
- 2. Go to the YSI 556 MPS file screen as described in Section
- **3.** Use the arrow keys to highlight the Upload to PC selection. See Figure 8.2 File Screen.
- **4.** Press the **Enter** key. The file list screen is displayed. See Figure 8.3 File List Screen.
- 5. Use the arrow keys to highlight the calibration record file that you wish to transfer and press Enter.
- 6. You will then be given a choice of uploading the file in three formats; Binary, Comma & "" Delimited, and ASCII Text.

NOTE: The binary format is reserved for future YSI software packages.

7. Choose an option and press Enter, both the YSI 556 and PC displays show the progress of the file transfer.

NOTE: After transfer, the file will be located in the C:\ECOWWIN\DATA folder of your PC, designated with the appropriate file extension.

NOTE: To view the Calibration Record data after upload, simply open the .txt file in a general text editor such as Wordpad or Notepad.

8. After the file transfer is complete, close the terminal window (small window on the PC) by clicking on the "X" at its upper right corner.

9. Press the **Escape** key repeatedly to return to the main menu screen.

8.5 File Memory

- 1. Go to the file screen as described in Section 8.1 Accessing the File Screen.
- **2.** Use the arrow keys to highlight the **File memory** selection. See Figure 8.2 File Screen.
- **3.** Press the **Enter** key. The file bytes used screen is displayed.




Figure 8.4 File Bytes Used Screen

4. The amount of free memory is listed in line 4 of the file bytes used screen.

NOTE: If the amount of free memory is low, it may be time to delete all files (after first uploading all data to a PC). Refer to Section 8.6 Delete All Files.

5. Press the **Escape** key repeatedly to return to the main menu screen.

Section 8 File

8.6 Delete All Files

NOTE: It is not possible to delete individual files in order to free up memory. The only way to free up memory is to delete ALL files present. Take care to transfer all files to your computer (refer to Section 8.4 Upload to PC) before deleting them.

- 1. Go to the file screen as described in Section 8.1 Accessing the File Screen.
- **2.** Use the arrow keys to highlight the **Delete all files** selection. See Figure 8.2 File Screen.
- **3.** Press the **Enter** key. The Delete all Files screen is displayed.




Figure 8.5 Delete All Files Screen

- **4.** Use the arrow keys to highlight the **Delete** selection.
- **5.** Press the **Enter** key.

File Section 8




Figure 8.10 Deleting

The progress of file deletion is displayed in bar graph format.

NOTE: Deleting all files in the directory will not change any information in the site list.

6. Press the Escape key repeatedly to return to the main menu screen.

9. Logging

9.1 Accessing the Logging Setup Screen

- 1. Press the On/off key to display the run screen.
- 2. Press the **Escape** key to display the main menu screen.




Figure 9.1 Main Menu

- 3. Use the arrow keys to highlight the **Logging setup** selection.
- 4. Press the Enter key. The logging setup screen is displayed.




Figure 9.2 Setup Screen

Page 66 YSI 556 MPS YSI Incorporated

Logging Section 9

9.2 Setting Logging Interval

Follow steps below to set the interval for logging a data stream.

NOTE: If you do not specify an interval, the instrument will use a default interval setting of 1 second.

NOTE: It is not necessary to set a logging interval when logging a single sample.

- **1.** Go to the logging setup screen as described in Section 9.1 Accessing the Logging Setup Screen.
- **2.** Use the keypad to enter an interval between 1 second and 15 minutes. Refer to Section 2.9 Keypad Use.

NOTE: The interval field has hour, minute and second entry fields. Any entry over 1 hour will change automatically to a 15-minute setting.

- 3. Press the Enter key. The data stream interval is set.
- **4.** Press the **Escape** key repeatedly to return to the main menu screen.

9.3 Storing Barometer Readings

NOTE: The **Store barometer** option is only available on instruments that are equipped with the optional barometer.

- **1.** Go to the logging setup screen as described in Section 9.1 Accessing the Logging Setup Screen.
- **2.** Use the arrow keys to highlight the **Store barometer** selection. See Figure 9.2 Logging Setup Screen.
- **3.** Press the **Enter** key until a check mark is entered in the box next to the store barometer selection if you want to log barometric readings.

Section 9 Logging

> OR press the **Enter** key until the box next to the barometer selection is empty if you do not want to log barometric readings.




Figure 9.3 Store Barometer

4. Press the **Escape** key repeatedly to return to the main menu screen.

Creating a Site List 9.4

The site list option allows you to define file and site descriptions in the office or laboratory before moving to field logging studies. This is usually more convenient than entering the information at the site and is particularly valuable if you are visiting certain sites on a regular basis. The following section describes how to set up site lists which contain entries designated "Site Descriptions" that will be instantly available to the user in the field to facilitate the logging of data with pre-established naming of files and sites. There are two kinds of **Site Descriptions** available for use in **Site lists**:

- Site Descriptions associated with applications where data from a single site is always logged to a single file. This type is referred to as a "Single-Site Description" and is characterized by two parameters – a file name and a site name. Files logged to YSI 556 MPS memory under a Single-Site **Description** will be characterized primarily by the file name, but will also have the Site name attached, so that it is viewable in either the YSI 556 MPS File directory or in EcoWatch for Windows after upload to a PC
- Site Descriptions associated with applications where data from multiple sites are logged to a single file. This type is referred to as a "Multi-site Description" and is characterized by three parameters – a file name, a site name, and a site number. Files logged to YSI 556 MPS memory under a

Page 68 **YSI 556 MPS** YSI Incorporated Logging Section 9

Multi-site Description are characterized by a file name, but not a site name, since multiple sites are involved. However, each data point has a Site Number attached to it so that the user can easily determine the sampling site when viewing the data from the YSI 556 MPS **File** menu or processing the data in EcoWatch for Windows after upload to a PC.




Figure 9.4 Single-Site Descriptions




Figure 9.5 Multiple-Site Descriptions

NOTE: Site lists containing Single Site Descriptions are usually input with the designation Store Site Number INACTIVE in the YSI 556 MPS Logging setup menu. Thus, no site numbers appear in the first Site list example. Conversely, Site lists containing Multi-Site Descriptions MUST be input with the Store Site Number selection ACTIVE as shown in the second example.

YSI Incorporated YSI 556 MPS Page 69

To create a site list:

- **1.** Go to the logging setup screen as described in Section 9.1 Accessing the Logging Setup Screen.
- 2. Use the arrow keys to highlight the Use site list selection.
- **3.** Press the **Enter** key. A check mark is entered in the box next to the use site list selection *and* two new entries appear on the logging setup screen. See Figure 9.6 Logging Setup Screen.




Figure 9.6 Logging Setup Screen

- **4.** Use the arrow keys to highlight the **Store site number** selection.
- 5. If you are creating Multi-Site Descriptions (which require that the site **number** be stored in your data files), press the **Enter** key until a check mark appears in the box next to the store site number selection.

OR Press the **Enter** key until the box next to the store site number selection is empty, to create Single-Site Descriptions. The site **name** will be stored in the header of your data files.

- **6.** Use the arrow keys to highlight the **Edit site list** selection.
- 7. Press the **Enter** key. The edit site list screen is displayed. See Figure 9.7 Edit Site List Screen. The **Filename** field is ready for input.




Figure 9.7 Edit Site List Screen

- **8.** Use the keypad to enter a filename up to 8 characters in length. Refer to Section 2.9 Keypad Use.
- **9.** Press the **Enter** key. The cursor moves to the right for the entry of a **Site name**.
- **10.** Use the keypad to enter a site name up to 11 characters in length. Refer to Section 2.9 Keypad Use.

NOTE: If the store site number selection is *not* checked, skip to Step 13.

- **11.** Press the **Enter** key. The cursor moves to the site number entry position.
- **12.** Use the keypad to enter a site number up to 7 characters in length. Refer to Section 2.9 Keypad Use.
- **13.** Press Enter. The cursor moves to the next filename entry position.
- **14.** Repeat Steps 8 to 13 until all filenames and sites have been entered.
- 15. Press Escape repeatedly to return to the main menu screen.

9.5 Editing a Site List

- **1.** Go to the logging setup screen as described in Section 9.1 Accessing the Logging Setup Screen.
- 2. Use the arrow keys to highlight the Edit Site List selection. See Figure 9.6 Logging Setup Screen.
- 3. Press the Enter key. The edit site list screen is displayed.
- **4.** Edit the site list using the keystrokes described below.


NOTE: Editing the site list will not have any effect on files stored in the instrument memory.

To MOVE a site:

Use the arrow keys to highlight a site. Press the Up or Down arrow key while holding down the Enter key.

To INSERT a site above another site:
Use the arrow keys to

highlight the site.
Press the Right arrow key while holding down the Enter key.
Use keypad to input letters. Refer to Section 2.9 Keypad Use.



To DELETE a site:
Use the arrow keys to highlight a site. Press the Left arrow key while holding down the Enter key.

To use the same file name as the previous site: Leave the filename blank

Figure 9.1 Keystrokes for Editing Site List

9.6 Logging Data Without a Site List

- 1. Follow Steps 1 through 5 in Section 7.1 Real-Time Data.
- 2. Use the arrow keys to highlight the Log one sample selection on the run screen if only a single sample is being logged.

OR Use the arrow keys to highlight the **Start logging** selection on the run screen if a data stream is being logged.




Figure 9.9 Run Screen

3. Press the **Enter** key. The Enter information screen is displayed.




Figure 9.10 Enter Information Screen

NOTE: The last filename used will be displayed.

4. Use the keypad to enter a file name. Refer to Section 2.9 *Keypad Use*.

NOTE: The instrument will assign a default file name of NONAME if no file name is specified.

5. Press the **Enter** key to input the file name.

6. Use the arrow keys to highlight the **Site description** field in the enter information screen.

NOTE: Entering a Site Description is optional. You may leave the Site Description blank and skip to Step 9.

- **7.** Use the keypad to enter a site description name. Refer to Section 2.9 Keypad Use.
- 8. Press the Enter key to input the site description.

NOTE: If you want to change the logging setup, such as sampling interval or storing the barometer reading, use the arrow keys to highlight the **Configure** field, press the **Enter** key, then refer to Section 9.2 Setting Logging Interval or 9.3 Storing Barometer Readings for details.

- **9.** Use the arrow keys to highlight the **OK** field in the center of the information screen.
- 10. Press the Enter key to start logging.

NOTE: If the parameter mismatch screen is displayed, refer to Section 9.8 Adding Data to Existing Files.

11. If a single point is being logged, the header on the run screen changes momentarily from Menu to Sample logged to confirm that the point was successfully logged. Skip to Step




Figure 9.11 Sample Logged Screen YSI 556 MPS

If a continuous stream of points is being logged, the start logging entry in the run screen changes from **Start logging** to **Stop logging**.




Figure 9.12 Logging Screen

- **12.** At the end of the logging interval, press **Enter** to stop logging.
- **13.** Refer to Section 8.3 View File to view the data on the instrument display.

9.7 Logging Data with a Site List

- 1. If you have not already created a site list, refer to Section 9.4 Creating a Site List.
- 2. Follow Steps 1 through 5 in Section 7.1 Real-Time Data.
- 3. Use the arrow keys to highlight the Log one sample selection on the run screen if only a single sample is being logged.
 - OR Use the arrow keys to highlight the **Start logging** selection on the run screen if a data stream is being logged. See Figure 9.9 Run Screen.
- 4. Press the Enter key. The Pick a site screen is displayed.




Figure 9.13 Pick a Site Screen

5. Use the arrow keys to highlight the **site** of your choice.

NOTE: If the site of your choice is grayed out in the site list, refer to Section 9.8 Adding Data to Existing Files.

NOTE: Refer to Section 9.5 Editing a Site List if you want to edit the site list.

6. Press the Enter key to start logging.

NOTE: If the parameter mismatch screen is displayed, refer to Section 9.8 Adding Data to Existing Files.

7. If a single point is being logged, the header on the run screen changes momentarily from **Menu** to **Sample logged** to confirm that the point was successfully logged. See Figure 9.11 Sample Logged Screen. Skip to Step 9.

If a continuous stream of points is being logged, the start logging entry in the run screen changes from **Start logging** to **Stop logging**. See Figure 9.12 Logging Screen.

8. At the end of the logging interval, press **Enter** to stop logging.

Logging Section 9

9. Refer to Section 8.3 View File to view the data on the instrument display.

9.8 Adding Data to Existing Files

In order to add new data to an existing file, the current logging and sensor setup must be *exactly* the same as when the file was created. The following settings must be the same:

- Sensors enabled (refer to Section 4 Sensors)
- **Store Barometer** (refer to Section 9.3 Storing Barometer Readings)
- Store Site Number (refer to Section 9.4 Creating a Site List)

If the current logging setup is not exactly the same as when the file was created, a parameter mismatch screen is displayed.




Figure 9.14 Parameter Mismatch Screen

NOTE: The right column shows parameters used when the file was created. The left column shows current parameters.

- 1. Press the **Down Arrow** key to scroll down and find the mismatch(es).
- 2. Use the following chart to resolve the mismatch(es).

Section 9 Logging

Mismatch	Action	Reference
Sensor(s) missing from left column	Enable the missing sensor(s)	Section 4 Sensors
Extra sensor(s) listed in left column	Disable the extra sensor(s)	Section 4 Sensors
Barometer missing from left column, but present in right column	Enable the Store Barometer setting	Section 9.3 Storing Barometer Readings
Barometer present in left column, but missing from right column	Disable the Store Barometer setting	Section 9.3 Storing Barometer Readings
Store Site Number	Enable the Store Site	Section 9.4 Creating a
missing from left column, but present in right column	Number setting	Site List
Store Site Number	Disable the Store Site	Section 9.4 Creating a
present in left column, but missing from right column	Number setting	Site List

3. Return to Section 9.6 Logging Data without a Site List or 9.7 Logging Data with a Site List.

Page 78 YSI 556 MPS YSI Incorporated

10. System Setup

The YSI 556 MPS has a number of features that are user-selectable or can be configured to meet the user's preferences. Most of these choices are found in the **System setup** menu.

10.1 Accessing the System Setup Screen

- 1. Press the On/off key to display the run screen. See Figure Front View of YSI 556 MPS.
- 2. Press the **Escape** key to display the main menu screen.
- **3.** Use the arrow keys to highlight the **System setup** selection.




Figure 10.1 Main Menu

4. Press the Enter key. The system setup screen is displayed.




Figure 10.2 System Setup Screen

NOTE: The first line of the **System setup** menu shows the current software version of your YSI 556 MPS. As software enhancements are introduced, you will be able to upgrade your YSI 556 MPS from the YSI Web site. Refer to Section 11.2 Upgrading YSI 556 MPS Software for details.

10.2 Language Setting

- **1.** Go to the System Setup screen as described in Section 10.1 Accessing the System Setup Screen.
- **2.** Use the arrow keys to highlight **Language** on the System Setup screen. Press **Enter** to open the Language screen. .
- 3. Use the arrow keys to highlight your desired Language. Press Enter.
- **4.** Press the Escape key repeatedly to return to the Main men

10.3 Date and Time Setup

1. Go to the system setup screen as described in Section 10.1 Accessing the System Setup Screen.

Page 80 YSI 556 MPS YSI Incorporated

System Setup Section 10

2. Use the arrow keys to highlight the **Date & time** selection on the system setup screen. See Figure 10.2 System Setup Screen.

3. Press Enter. The date and time setup screen is displayed.




Figure 10.3 Date Setup Screen

NOTE: A black dot to the left of a date format indicates that format is selected.

- **4.** Use the arrow keys to highlight your desired date format.
- 5. Press Enter.
- **6.** Use the arrow keys to highlight the 4-digit year selection.
- 7. Press Enter. A check mark appears in the check box next to the 4-digit year selection.

NOTE: If unchecked, a 2-digit year is used.

- **8.** Use the arrow keys to highlight the **Date** selection.
- **9.** Press **Enter**. A cursor appears over the first number in the date.

Section 10 System Setup

10. Enter the proper number from the keypad for the highlighted date digit. The cursor moves automatically to the next date digit. Refer to Section 2.9 Keypad Use for more keypad information.

- 11. Repeat Step 10 until all date digits are correct.
- 12. Press Enter to input the specified date.
- **13.** Use the arrow keys to highlight the **Time** selection.
- **14.** Press Enter. A cursor appears over the first number in the time selection.
- **15.** Enter the proper number from the keypad for the highlighted time digit. The cursor moves automatically to the next time digit.

NOTE: Use military format when entering time. For example, 2:00 PM is entered as 14:00.

- **16.** Repeat Step 15 until all time digits are correct.
- 17. Press Enter to input the correct time.
- **18.** Press the **Escape** key repeatedly to return to the Main menu screen.

10.4 Data Filter

The Data Filter is a software filter that eliminates sensor noise and provides more stable readings.

NOTE: YSI recommends using the default values for the data filter for most field applications.

However, users who are primarily interested in a fast response from their dissolved oxygen sensor should consider a change of the default time constant setting of 8 seconds to one of 2 seconds. This change can be made according to the instructions in Section 10.3.1 Changing the Data Filter Settings below. The disadvantage of lowering the time constant is that field pH readings may appear somewhat noisy if the cable is in motion.

Page 82 YSI 556 MPS YSI Incorporated

System Setup Section 10

10.4.1 Changing the Data Filter Settings

1. Go to the system setup screen as described in Section 10.1 Accessing the System Setup Screen.

- **2.** Use the arrow keys to highlight the **Data filter** selection. See Figure 10.1 Main Menu.
- **3.** Press the **Enter** key. The Data filter setup screen is displayed.




Figure 10.4 Data Filter Screen

- **4.** With Enabled highlighted, press the **Enter** key to Enable or Disable the data filter. A black dot to the left of the selection indicates the data filter is enabled.
- 5. Use the arrow keys to highlight the **Time constant** field.

NOTE: This value is the time constant in seconds for the software data filter. Increasing the time constant will result in greater filtering of the data, but will also slow down the apparent response of the sensors.

6. Use the keypad to enter a value. The default value is 8 and this value is ideal for most 556 field applications. As described in Section 10.3 Data Filter above, users who wish to decrease the response time of the DO readings at the expense of some noise for the pH readings determined

YSI Incorporated YSI 556 MPS Page 83

concurrently, should change the Time Constant to a value of 2.

- 7. Press the Enter key to enter the time constant.
- 8. Use the arrow keys to highlight the Threshold field.

NOTE: This value determines when the software data filter will engage/disengage, speeding the response to large changes in a reading. When the difference between two consecutive readings is larger than the threshold, then the reading is displayed unfiltered. When the difference between two consecutive readings drops below the threshold, readings will be filtered again.

- **9.** Use the keypad to enter a value. The default value is 0.01.
- 10. Press the Enter key to enter the threshold.
- **11.** Press the **Escape** key repeatedly to return to the Main menu screen.

10.5 Shutoff Time

The YSI 556 MPS shuts off automatically after 30 minutes of inactivity. The shut off time may be changed as described below.

- **1.** Go to the system setup screen as described in Section 10.1 Accessing the System Setup Screen.
- **2.** Use the arrow keys to highlight the **Shutoff time** selection on the system setup screen. See Figure 10.2 System Setup Screen.
- **3.** Use the keypad to enter a value from 0 to 60 minutes. The default value is 30.

NOTE: To disable the automatic shutoff feature, enter a zero (0).

4. Press the **Enter** key to enter the correct shutoff time.

YSI 556 MPS

YSI Incorporated

System Setup Section 10

5. Press the **Escape** key repeatedly to return to the main menu screen.

10.6 Comma Radix

The user can toggle between a period (default) and comma for the radix mark by selecting this item and pressing the **Enter** key as follows:

- **1.** Go to the system setup screen as described in Section 10.1 Accessing the System Setup Screen.
- **2.** Use the arrow keys to highlight the **Comma radix** selection on the system setup screen. See Figure 10.2 System Setup Screen.
- **3.** Press the **Enter** key. A check mark appears in the check box next to the comma radix selection indicating that the radix mark is a comma.

10.7 ID

This selection allows you to enter an identification name/number for your YSI 556 MPS. This ID name/number is logged in the header of each file.

- **1.** Go to the system setup screen as described in Section 10.1 Accessing the System Setup Screen.
- 2. Use the arrow keys to highlight the **ID** selection. See Figure 10.1 Main Menu.
- **3.** Use the keypad to enter an alphanumeric ID up to 15 characters in length. Refer to Section 2.9 Keypad Use.
- 4. Press the Enter key to enter the ID.
- **5.** Press the **Escape** key repeatedly to return to the main menu screen.

10.8 GLP Filename

This selection allows you to enter a different filename for the YSI 556 MPS Calibration Record file.

YSI Incorporated YSI 556 MPS Page 85

Section 10 System Setup

NOTE: The default filename is the "556 PC board Serial Number.glp."

- **1.** Go to the system setup screen as described in Section 10.1 Accessing the System Setup Screen.
- 2. Use the arrow keys to highlight the GLP Filename selection. See Figure 10.1 Main Menu.
- **3.** Use the keypad to enter a filename up to 8 characters in length. Refer to Section 2.9 Keypad Use.
- **4.** Press the **Enter** key to enter the new filename.
- **5.** Press the **Escape** key repeatedly to return to the main menu screen.

10.9 TDS Constant

This selection allows you to set the constant used to calculate Total Dissolved Solids (TDS). TDS in g/L is calculated by multiplying this constant times the specific conductance in mS/cm.

10.9.1 Changing the TDS Constant

- **1.** Go to the system setup screen as described in Section 10.1 Accessing the System Setup Screen.
- **2.** Use the arrow keys to highlight the **TDS Constant** selection. See Figure 10.1 Main Menu.
- **3.** Use the keypad to enter a value. Refer to Section 2.9 Keypad Use. The default value is 0.65.
- **4.** Press the **Enter** key to enter the correct TDS constant.
- **5.** Press the **Escape** key repeatedly to return to the main menu screen.

Page 86 YSI 556 MPS YSI Incorporated

System Setup Section 10

10.10 Barometer Units

The following information is only for instruments with the barometer option.

- **1.** Go to the system setup screen as described in Section 10.1 Accessing the System Setup Screen.
- **2.** Use the arrow keys to highlight the **Barometer units** selection on the system setup screen. See Figure 10.2 System Setup Screen.
- 3. Press the Enter key. The Barometer units screen will appear.




Figure 10.5 Data Filter Screen

A black dot indicates the currently selected units.

- 4. Use the arrow keys to highlight your desired barometric unit.
- **5.** Press the **Enter** key to select your choice. A black dot will appear in the circle next to your selected units.
- **6.** Press the **Escape** key repeatedly to return to the main menu screen.

Section 10 System Setup

10.11 Calibrate Barometer

The optional barometer has been factory calibrated to provide accurate readings. However, some sensor drift may occur over time, requiring occasional calibration by the user, as follows:

- 1. Determine your local barometric pressure from an independent laboratory barometer or from your local weather service.
- **2.** If the barometric pressure (BP) reading is from your local weather station, reverse the equation that corrects it to sea level.

NOTE: For this equation to be accurate, the barometric pressure units must be in mmHg.

True BP = (Corrected BP) - [2.5 * (Local Altitude/100)]

- **3.** Go to the system setup screen as described in Section 10.1 Accessing the System Setup Screen.
- **4.** Use the arrow keys to highlight the **Calibrate barometer** selection on the system setup screen. See Figure 10.2 System Setup Screen.
- **5.** Press the **Enter** key. The Calibrate Barometer screen is displayed.




Figure 10.6 Barometer Calibration Screen

Page 88 YSI 556 MPS YSI Incorporated

System Setup Section 10

6. Use the keypad to input the known barometric pressure value as determined in Step 2.

- 7. Press the **Enter** key. The new barometer reading is displayed as well as the approximate offset from the factory reading.
 - **NOTE:** To return the sensor to the factory setting, subtract the offset amount from the current setting and repeat Steps 5 to 7.

Page 89

8. Press the **Escape** key repeatedly to return to the main menu screen.

11. Maintenance

11.1 Sensor Care and Maintenance

Once the sensors have been properly installed, remember that periodic cleaning and DO membrane changes are required.

11.1.1 **DO** Sensor

For best results, we recommend that the KCl solution and the membrane cap be changed at least once every 30 days.

- 1. It is important to recognize that oxygen dissolved in the sample is consumed during sensor operation. It is therefore essential that the sample be continuously stirred at the sensor tip. If stagnation occurs, your readings will be artificially low. Stirring may be accomplished by mechanically moving the sample around the sensor tip, or by rapidly moving the sensor through the sample. The rate of stirring should be at least 1 foot per second.
- 2. Membrane life depends on usage. Membranes will last a long time if installed properly and treated with care. Erratic readings are a result of loose, wrinkled, damaged, or fouled membranes, or from large (more than 1/8" diameter) bubbles in the electrolyte reservoir. If erratic readings or evidence of membrane damage occurs, you should replace the membrane and the electrolyte solution. The average replacement interval is two to four weeks.
- **3.** If the membrane is coated with oxygen consuming (e.g. bacteria) or oxygen producing organisms (e.g. algae), erroneous readings may occur.
- **4.** Chlorine, sulfur dioxide, nitric oxide, and nitrous oxide can affect readings by behaving like oxygen at the sensor. If you suspect erroneous readings, it may be necessary to determine if these gases are the cause.
- 5. Avoid any environment that contains substances that may attack the probe module and sensor materials. Some of these substances are concentrated acids, caustics, and strong solvents. The sensor materials that come in contact

Maintenance Section 11

with the sample include FEP Teflon, acrylic plastic, EPR rubber, stainless steel, epoxy, polyetherimide and the PVC cable covering.

- **6.** It is possible for the silver anode, which is the entire silver body of the sensor, to become contaminated. This will prevent successful calibration. To restore the anode, refer to Section 11.1.1 DO Sensor, Silver Anode Cleaning.
- 7. For correct sensor operation, the gold cathode must always be bright. If it is tarnished (which can result from contact with certain gases), or plated with silver (which can result from extended use with a loose or wrinkled membrane), the gold surface must be restored. To restore the cathode, refer to Section 11.1.1 DO Sensor, Gold Cathode Cleaning.
- 8. To keep the electrolyte from drying out, store the sensor in the transport/calibration cup with at least 1/8" of water.

Silver Anode Cleaning

After extended use, a thick layer of AgCl builds up on the silver anode reducing the sensitivity of the sensor. The anode must be cleaned to remove this layer and restore proper performance. The cleaning can be chemical or mechanical:

Chemical Cleaning: Remove the membrane cap and soak the entire anode section in a 14% ammonium hydroxide solution for 2 to 3 minutes, followed by a thorough rinsing with distilled or deionized water. The anode should then be thoroughly wiped with a wet paper towel to remove the residual layer from the anode.

Mechanical Cleaning: Sand off the dark layer from the silver anode with 400 grit wet/dry sandpaper. Wrap the sandpaper around the anode and twist the sensor. Rinse the anode with clean water after sanding, followed by wiping thoroughly with a wet paper towel.

NOTE: After cleaning, a new membrane cap must be installed. Refer to Section 3.4.3 Membrane Cap Installation.

Turn the instrument on and allow the system to stabilize for at least 30 minutes. If, after several hours, you are still unable to calibrate, contact your dealer or YSI Customer Service. Refer to *Appendix E Customer Service*.

Section 11 Maintenance

Gold Cathode Cleaning

For correct sensor operation, the gold cathode must be textured properly. It can become tarnished or plated with silver after extended use. The gold cathode can be cleaned by using the adhesive backed sanding disc and tool provided in the YSI 5238 Probe Reconditioning Kit.

Using the sanding paper provided in the YSI 5238 Probe Reconditioning Kit, wet sand the gold with a twisting motion about 3 times or until all silver deposits are removed and the gold appears to have a matte finish. Rinse the cathode with clean water after sanding, followed by wiping thoroughly with a wet paper towel. If the cathode remains tarnished, contact your dealer or YSI Customer Service. Refer to *Appendix E Customer Service*.

NOTE: After cleaning, a new membrane cap must be installed. Refer to Section 3.4.3 Membrane Cap Installation.

11.1.2 DO Sensor Replacement

1. Remove the probe sensor guard.

CAUTION: Thoroughly dry the sensor so that no water enters the probe module sensor port when the sensor is removed.

- 2. Insert the long end of the hex key wrench into the small hole in the side of the probe module bulkhead. Turn the wrench counterclockwise and remove the screw. (You do not have to remove the screw all the way to release the sensor.)
- **3.** Pull the old DO sensor module straight out of the probe module body.

NOTE: The DO sensor is not threaded, it is keyed, so it cannot be removed by twisting.

Page 92 YSI 556 MPS YSI Incorporated

Maintenance Section 11




Figure 11.1 DO Sensor Replacement

4. Insert the new DO sensor module. Make sure that the inside of the probe module sensor port and the o-ring on the sensor are clean, with no contaminants, such as grease, dirt, or hair. The DO sensor is keyed, or has a flat side, so that it cannot be aligned improperly.

NOTE: Make sure the DO sensor bottoms out before the set screw is inserted.

5. Insert the set screw into the small hole in the side of the probe module bulkhead, and turn clockwise to rethread.

CAUTION: Make sure that you do not cross-thread the set screw. Use the hex key wrench to tighten the screw in properly, making sure that the screw does not stick out of the side of the probe module bulkhead. The probe sensor guard will not thread on properly and damage may result if the screw is allowed to stick out.

Section 11 Maintenance

NOTE: The YSI 5563 DO sensor is shipped dry. A shipping membrane was installed to protect the electrode. A new membrane cap must be installed before the first use. Refer to Section 3.4.1 Sensor Installation.

11.1.3 YSI 5564 pH and 5565 Combination pH/ORP Sensor Cleaning

Cleaning is required whenever deposits or contaminants appear on the glass and/or platinum surfaces of these sensors or when the response of the sensor becomes slow.

- **1.** Remove the sensor from the probe module.
- 2. Initially, simply use clean water and a soft clean cloth, lens cleaning tissue, or cotton swab to remove all foreign material from the glass bulb (YSI 5564 and YSI 5565) and platinum button (YSI 5565). Then use a moistened cotton swab to carefully remove any material that may be blocking the reference electrode junction of the sensor.

CAUTION: When using a cotton swab with the YSI 5564 or YSI 5565, be careful NOT to wedge the swab tip between the guard and the glass sensor. If necessary, remove cotton from the swab tip, so that the cotton can reach all parts of the sensor tip without stress.

NOTE: If good pH and/or ORP response is not restored by the above procedure, perform the following additional procedure:

- 1. Soak the sensor for 10-15 minutes in clean water containing a few drops of commercial dishwashing liquid.
- **2.** GENTLY clean the glass bulb and platinum button by rubbing with a cotton swab soaked in the cleaning solution.
- **3.** Rinse the sensor in clean water, wipe with a cotton swab saturated with clean water, and then re-rinse with clean water.

NOTE: If good pH and/or ORP response is still not restored by the above procedure, perform the following additional procedure:

Page 94 YSI 556 MPS YSI Incorporated

Maintenance Section 11

1. Soak the sensor for 30-60 minutes in one molar (1 M) hydrochloric acid (HCl). This reagent can be purchased from most distributors. Be sure to follow the safety instructions included with the acid.

- **2.** GENTLY clean the glass bulb and platinum button by rubbing with a cotton swab soaked in the acid.
- **3.** Rinse the sensor in clean water, wipe with a cotton swab saturated with clean water, and then re-rinse with clean water. To be certain that all traces of the acid are removed from the sensor crevices, soak the sensor in clean water for about an hour with occasional stirring.

NOTE: If biological contamination of the reference junction is suspected or if good response is not restored by the above procedures, perform the following additional cleaning step:

- 1. Soak the sensor for approximately 1 hour in a 1 to 1 dilution of commercially available chlorine bleach.
- 2. Rinse the sensor with clean water and then soak for at least 1 hour in clean water with occasional stirring to remove residual bleach from the junction. (If possible, soak the sensor for period of time longer than 1 hour in order to be certain that all traces of chlorine bleach are removed.) Then re-rinse the sensor with clean water and retest.`

11.1.4 Temperature/Conductivity Sensor Cleaning

The single most important requirement for accurate and reproducible results in conductivity measurement is a clean cell. A dirty cell will change the conductivity of a solution by contaminating it. The small cleaning brush included in the YSI 5511 Maintenance Kit is ideal for this purpose.

To clean the conductivity cell:

- **1.** Dip the brush in clean water and insert it into each hole 1520 times.
- 2. Rinse the cell thoroughly in deionized or clean tap water.

Section 11 Maintenance

NOTE: In the event that deposits have formed on the electrodes, perform the following additional procedure:

- 1. Use a mild detergent solution in combination with the brush. Dip the brush in the solution and insert it into each hole 1520 times.
- **2.** Rinse the cell thoroughly in deionized or clean tap water.

NOTE: After cleaning, check the response and accuracy of the conductivity cell with a calibration standard.

NOTE: If this procedure is unsuccessful, or if sensor performance is impaired, it may be necessary to return the sensor to a YSI authorized service center for service, Refer to *Appendix E Customer Service*.

The temperature portion of the sensor requires no maintenance.

11.2 Upgrading YSI 556 MPS Software


- **1.** Access the YSI Environmental Software Downloads page as described in *Appendix G EcoWatch* Step 1 through 3.
- 2. Click on the YSI Instruments Software Updates link (or scroll down until you see YSI 556 MPS).
- 3. Click on the file icon to the right of the YSI 556 MPS listing and save the file to a temporary directory on your computer.
- **4.** After the download is complete, run the file (that you just downloaded) and follow the on screen instructions to install the YSI Code Updater on your computer. If you encounter difficulties, contact YSI customer service for advice. Refer to *Appendix E Customer Service*.
- **5.** If necessary, disconnect the YSI 5563 Probe Module from the YSI 556 MPS instrument.

Page 96 YSI 556 MPS YSI Incorporated

Maintenance Section 11


6. Connect the YSI 556 MPS to a serial port of your computer via the 655173 PC interface cable. See Figure 8.6 Computer/Instrument Interface.

- 7. Press the On/off key on the YSI 556 MPS to display the run screen.
- **8.** Run the YSI Code Updater software that you just installed on your computer. The following window will be displayed:




9. Set the Comm port number to match the port that you connected the 655173 PC Interface Cable to, then click on the Start Code Update button.

The YSI 556 MPS screen will blank out and a progress indicator will be displayed on the PC.



When the update is finished (indicated on the PC screen), the YSI 556 MPS will return to the Run screen. See Figure 7.1 Run Screen.



Section 11 Maintenance

10. Close the YSI Code Updater window (on the PC) by clicking on the "X" in the upper right corner of the window.

11. Disconnect the YSI 556 MPS from the 655173 PC interface cable and reconnect it to the YSI 5563 Probe Module. Refer to Section 3.6 Instrument/Cable Connection.

Page 98 YSI 556 MPS YSI Incorporated

12. Storage

Proper storage between periods of usage will not only extend the life of the sensors, but will also ensure that the unit will be ready to use as quickly as possible in your next application.

12.1 General Recommendations for Short Term Storage

No matter what sensors are installed in the instrument, it is important to keep them moist without actually immersing them in liquid. Immersing them could cause some of them to drift or result in a shorter lifetime.

YSI recommends that short term storage of all multi-parameter instruments be done by placing approximately 1/2 inch of tap water in the transport/calibration cup that was supplied with the instrument, and by placing the probe module with all of the sensors installed into the cup. The use of a moist sponge instead of a 1/2 inch of tap water is also acceptable, as long as its presence does not compromise the attachment of the cup to the probe module. The transport/calibration cup should be sealed to prevent evaporation.

NOTE: Ensure that an o-ring is installed in the o-ring groove on the threaded end of the probe module body. See Figure 3.7 Transport/Calibration Cup Installation.



CAUTION: The water level has to be low enough so that none of the sensors are actually under water. Check the transport/calibration cup periodically to make certain that the water is still present or the sponge is still moist.

NOTE: If the storage water (tap water) is accidentally lost during field use, environmental water can be used.

12.2 General Recommendations for Long Term Storage

12.2.1 Probe Module Storage

- 1. Remove the pH or pH/ORP sensor from the probe module and store according to the individual sensor storage instructions found in Section 12.2.2 Sensor Storage.
- **2.** Seal the empty port with the provided port plug.

NOTE: Leave the conductivity/temperature sensor and

YSI 556 MPS Page 99 YSI Incorporated

dissolved oxygen sensor, with membrane cap still on, in the probe module.

3. Place 1/2" of water, deionized, distilled or tap, in the transport/calibration cup.

CAUTION: The water level has to be low enough so that none of the sensors are actually under water. Check the transport/calibration cup periodically to make certain that the water is still present or the sponge is still moist.

4. Insert the probe module into the cup.

NOTE: Ensure that an o-ring is installed in the o-ring groove on the threaded end of the probe module body. See Figure 3.7 Transport/Calibration Cup Installation.

12.2.2 Sensor Storage

Temperature/Conductivity Sensor

No special precautions are required. Sensor can be stored dry or wet, as long as solutions in contact with the thermistor and conductivity electrodes are not corrosive (for example, chlorine bleach). However, it is recommended that the sensor be cleaned with the provided brush prior to long term storage. Refer to Section 11.1.4 Temperature/Conductivity Sensor Cleaning.

pH and Combination pH/ORP Sensor

The key to sensor storage is to make certain that the reference electrode junction does not dry out. Junctions which have been allowed to dry out due to improper storage procedures can usually be rehydrated by soaking the sensor for several hours (overnight is recommended) in a solution which is 2 molar in potassium chloride. If potassium chloride solution is not available, soaking the sensor in tap water or commercial pH buffers may restore sensor function. However in some cases the sensor may have been irreparably damaged by the dehydration and will require replacement.

CAUTION: Do not store the sensor in distilled or deionized water as the glass sensor may be damaged by exposure to this medium.

1. Remove the pH or pH/ORP sensor from the probe module.

Page 100 YSI 556 MPS YSI Incorporated

Storage Section 12

- **2.** Seal the empty port with the provided port plug.
- **3.** Place the sensor in the storage vessel (plastic boot or bottle) which was on the sensor at delivery. The vessel should contain a solution which is 2 molar in potassium chloride.

NOTE: Make certain that the vessel is sealed to prevent evaporation of the storage solution.

13. Troubleshooting

The following sections describe problems you may encounter when using the YSI 556 MPS and provides suggestions to overcome the symptom.

PROBLEM	POSSIBLE SOLUTION	
Display Problems		
No display is visible after pressing the on/off key.	If C cells are used, make certain that they are installed properly with regard to polarity and that good batteries are used. If a rechargeable battery pack is used, place the pack in the instrument and charge for 30 minutes.	
Instrument software appears to be locked up as evidenced by no response to keypad entries or display not changing.	First, attempt to reset the instrument by simply turning off and then on again. If this fails, remove battery power from the instrument for 30 seconds and then reapply power. When using C cells, remove the battery lid and one of the batteries; when using the rechargeable battery pack, remove the pack completely from the instrument. After 30 seconds replace the battery or battery pack and check for instrument function.	
The 556 display flashes and the instrument speaker makes a continuous clicking sound.	The battery voltage is low. Change to new C cells or recharge the 6117 battery pack.	
Water Damage to Instrument		
Leakage detected in battery compartment when using C cells.	Dispose of batteries properly. Dry the battery compartment using compressed air if possible. If corrosion is present on battery terminals, contact YSI Customer Service.	
Water has contacted rechargeable battery pack.	Remove battery pack immediately. Send battery pack to YSI Product Service for evaluation. CAUTION: DO NOT REUSE BATTERY PACK UNTIL YSI PRODUCT SERVICE HAS EVALUATED IT.	
Leakage suspected into the main cavity of the instrument case.	Remove the batteries immediately. Return the instrument to YSI Product Service.	

Section 13 Troubleshooting

PROBLEM POSSIBLE SOLUTIONS **Optional Cigarette Lighten Charger** Power cord fuse blown. 1. Unscrew adapter's cap, remove tip and pull out fuse. 2. Replace fuse with a new 2-amp fast-blow fuse from an Adapter Cap electronics store such as Radio Shack. 3. Reassemble the adapter and securely screw the cap back Power Cord onto the adapter body. (Positive Tip) File Problems Upload of files from YSI 556 1. Make sure that cable is connected properly to both 556 MPS to PC fails 2. Make certain that the proper Comm port is selected in EcoWatch for Windows. Barometer data is not stored Make sure Store barometer is active in the 556 Logging with sensor data file. setup menu. Site Descriptions in the Site There is a parameter mismatch between the current 556 List are "grayed-out" and not setup and that initially used. Change the current logging and available for appending files sensor setup to match the setup that was initially used to with additional data. create the file. **Sensor Problems** Sensor not properly calibrated. Follow DO cal procedures. Dissolved Oxygen Membrane not properly installed or may be punctured. reading is unstable or Replace membrane cap. inaccurate. Out of Range DO sensor electrodes require cleaning. Follow DO cleaning message appears during procedure. Use 5511 Maintenance kit. calibration. Water in sensor connector. Dry connector; reinstall sensor. Algae or other contaminant clinging to DO sensor. Rinse DO sensor with clean water. Barometric pressure entry is incorrect. Repeat DO cal procedure. Calibrated at extreme temperature. Recalibrate at (or near) sample temperature. DO sensor has been damaged. Replace sensor. Internal failure. Return probe module for service.

Troubleshooting Section 13

PROBLEM	POSSIBLE SOLUTIONS
Sensor Problems	
pH or ORP readings are unstable or inaccurate. Out of	Sensor requires cleaning. Follow sensor cleaning procedure.
Range message appears during	Sensor requires calibration. Follow cal procedures.
calibration.	pH sensor reference junction has dried out from improper storage. Soak sensor in tap water or buffer 4 until readings become stable.
	Water in sensor connector. Dry connector; reinstall sensor.
	Sensor has been damaged. Replace sensor.
	Calibration solutions out of spec or contaminated with other solution. Use new calibration solutions
	ORP fails Zobell check. Take into account temperature
	dependence of Zobell solution readings.
	Internal failure. Return probe module for service.
Conductivity unstable or inaccurate. Out of Range	Conductivity improperly calibrated. Follow calibration procedure.
message appears during calibration	Conductivity sensor requires cleaning. Follow cleaning procedure.
	Conductivity sensor damaged. Replace sensor.
	Calibration solution out of spec or contaminated. Use new calibration solution.
	Internal failure. Return probe module for service.
	Calibration solution or sample does not cover entire sensor. Immerse sensor fully.
Temperature, unstable or	Water in connector. Dry connector; reinstall sensor.
inaccurate	Sensor has been damaged. Replace the 5560 sensor.
Installed sensor has no reading	The sensor has been disabled. Enable sensor.
	Water in sensor connector. Dry connector; reinstall sensor.
	Sensor has been damaged. Replace sensor.
	Report output improperly set up. Set up report output.
	Internal failure. Return probe module for service.

If these guidelines and tips fail to correct your problem or if any other symptoms occur, contact YSI Customer Service for Advice. Refer to *Appendix E Customer Service*.

14. Appendix A YSI 556 MPS Specifications

For the most recent product specifications, please visit the YSI website: www.ysi.com

15. Appendix B Instrument Accessories

ITEM#	ACCESSORY
5563-4	4m Cable with DO/temp/conductivity
5563-10	10m Cable with DO/temp/conductivity
5563-20	20m Cable with DO/temp/conductivity
5564	pH Kit
5565	pH/ORP Kit
6118	Rechargeable Battery Pack Kit for use in US
5094	Rechargeable Battery Pack Kit with universal charger and three adapter cables for use in international applications
5095	Rechargeable Battery Pack Kit with universal charger and two adapter cables for use in international applications
5083	Flow Cell – probe module is secured in the flow cell and groundwater is
	pumped through it. Displaced volume approx. 475 ml
3059	Flow Cell, low volume. Displaced volume approx. 200 ml
116505	Battery Lid
616	Charger, Cigarette Lighter – used to power up the instrument from a car's cigarette lighter
4654	Tripod
614	Ultra Clamp, C Clamp –used to clamp the instrument to a table top or car dashboard
6081	Large Carrying Case, Hard-sided
5085	Hands-free Harness
5065	Carrying Case, Form-fitted, for use in the field – has a clear vinyl window, shoulder strap, belt loop strap and hand strap

16. Appendix C Required Federal Communications Notice

The Federal Communications Commission defines this product as a computing device and requires the following notice.

This equipment generates and uses radio frequency energy and if not installed and used properly, may cause interference to radio and television reception. It has been type tested and found to comply with the limits for a Class A or Class B computing device in accordance with the specification in Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient the receiving antenna
- Relocate the computer with respect to the receiver
- Move the computer away from the receiver
- Plug the computer into a different outlet so that the computer and receiver are on different branch circuits.

If necessary, the user should consult the dealer or an experienced radio/television technician for additional suggestions. The user may find the following booklet, prepared by the Federal Communications Commission, helpful: "How to Identify and Resolve Radio-TV Interference Problems". This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402, Stock No.0004-000-00345-4.

17. Appendix D Health Safety

YSI Conductivity Solutions: 3161, 3163, 3165, 3167, 3168, 3169

INGREDIENTS:

- o **Iodine**
- o Potassium Chloride
- o Water

WARNING: INHALATION MAY BE FATAL

⚠ CAUTION: AVOID INHALATION, SKIN CONTACT, EYE CONTACT OR INGESTION. MAY EVOLVE TOXIC FUMES IN FIRE.

Harmful if ingested or inhaled. Skin or eye contact may cause irritation. Has a corrosive effect on the gastro-intestinal tract, causing abdominal pain, vomiting, and diarrhea. Hyper-sensitivity may cause conjunctivitis, bronchitis, skin rashes etc. Evidence of reproductive effects.

FIRST AID:

INHALATION: Remove victim from exposure area. Keep warm and rest. In severe cases seek medical attention.

SKIN CONTACT: Remove contaminated cloth immediately. Wash affected area thoroughly with large amounts of water. In severe cases seek medical attention.

EYE CONTACT: Wash eyes immediately with large amounts of water, (approx. 10 minutes). Seek medical attention immediately.

INGESTION: Wash out mouth thoroughly with large amounts of water. Seek medical attention immediately.

YSI pH 4.00, 7.00, y 10.00: 3821, 3822, 3823

pH 4 INGREDIENTS:

- Potassium Hydrogen Phthalate
- o Formaldehyde
- Water

pH 7 INGREDIENTS:

- o Sodium Phosphate, Dibasic
- o Potassium Phosphate, Monobasic
- Water

pH 10 INGREDIENTS:

- Potassium Borate, Tetra
- o Potassium Carbonate
- o Potassium Hydroxide
- o Sodium (di) Ethylenediamine Tetraacetate
- Water

A CAUTION -AVOID INHALATION, SKIN CONTACT, EYE CONTACT OR INGESTION. MAY AFFECT MUCOUS MEMBRANES.

Inhalation may cause severe irritation and be harmful. Skin contact may cause irritation; prolonged or repeated exposure may cause Dermatitis. Eye contact may cause irritation or conjunctivitis. Ingestion may cause nausea, vomiting and diarrhea.

FIRST AID:

INHALATION – Remove victim from exposure area to fresh air immediately. If breathing has stopped, give artificial respiration. Keep victim warm and at rest. Seek medical attention immediately.

SKIN CONTACT – Remove contaminated clothing immediately. Wash affected area with soap or mild detergent and large amounts of water (approx. 15-20 minutes). Seek medical attention immediately.

EYE CONTACT - Wash eyes immediately with large amounts of water (approx. 15-20 minutes), occasionally lifting upper and lower lids. Seek medical attention immediately.

INGESTION – If victim is conscious, immediately give 2 to 4 glasses of water and induce vomiting by touching finger to back of throat. Seek medical attention immediately.

YSI Zobell Solution: 3682

INGREDIENTS:

- o Potassium Chloride
- Potassium Ferrocyanide Trihydrate
- o Potassium Ferricyanide

△ CAUTION -AVOID INHALATION, SKIN CONTACT, EYE CONTACT OR INGESTION. MAY AFFECT MUCOUS MEMBRANES.

May be harmful by inhalation, ingestion, or skin absorption. Causes eye and skin irritation. Material is irritating to mucous membranes and upper respiratory tract. The chemical, physical, and toxicological properties have not been thoroughly investigated.

Ingestion of large quantities can cause weakness, gastrointestinal irritation and circulatory disturbances.

FIRST AID:

INHALATION – Remove victim from exposure area to fresh air immediately. If breathing has stopped, give artificial respiration. Keep victim warm and at rest. Seek medical attention immediately.

SKIN CONTACT – Remove contaminated clothing immediately. Wash affected area with soap or mild detergent and large amounts of water (approx. 15-20 minutes). Seek medical attention immediately.

EYE CONTACT - Wash eyes immediately with large amounts of water (approx. 15-20 minutes), occasionally lifting upper and lower lids. Seek medical attention immediately.

INGESTION – If victim is conscious, immediately give 2 to 4 glasses of water and induce vomiting by touching finger to back of throat. Seek medical attention immediately.

18. Appendix E Customer Service

18.1 Ordering and Technical Support

Telephone:

800 897 4151 (US)

+1 937 767 7241 (Globally)

Monday through Friday, 8:00 AM to 5:00 ET

Fax:

+1 937 767 9353 (orders)

+1 937 767 1058 (technical support)

Email:

environmental@ysi.com or proseries@ysi.com

Mail:

YSI Incorporated

1725 Brannum Lane

Yellow Springs, OH 45387 USA

Website:

www.ysi.com

18.2 YSI Authorized Service Centers

YSI has authorized service centers throughout the United States and Internationally. For the nearest service center information, please visit www.ysi.com and click 'Support' or contact YSI Technical Support directly at 800-897-4151.

When returning a product for service, include the Product Return form with cleaning certification. The form must be completely filled out for a YSI Service Center to accept the instrument for service. The form may be downloaded from www.ysi.com by clicking on the 'Support' tab, then the Product Return Form button.

18.3 Cleaning Instructions

Equipment exposed to biological, radioactive, or toxic materials must be cleaned and disinfected before being serviced. Biological contamination is presumed for any instrument, probe, or other device that has been used with body fluids or tissues, or with wastewater. Radioactive contamination is presumed for any instrument, probe or other device that has been used near any radioactive source.

If an instrument, probe, or other part is returned or presented for service without a Cleaning Certificate, and if in our opinion it represents a potential

Appendix E Customer Service

biological or radioactive hazard, our service personnel reserve the right to withhold service until appropriate cleaning, decontamination, and certification has been completed. We will contact the sender for instructions as to the disposition of the equipment. Disposition costs will be the responsibility of the sender.

When service is required, either at the user's facility or at a YSI Service Center, the following steps must be taken to ensure the safety of service personnel.

- In a manner appropriate to each device, decontaminate all exposed surfaces, including any containers. 70% isopropyl alcohol or a solution of 1/4-cup bleach to 1-gallon tap water is suitable for most disinfecting. Instruments used with wastewater may be disinfected with .5% Lysol if this is more convenient to the user.
- The user shall take normal precautions to prevent radioactive contamination and must use appropriate decontamination procedures should exposure occur.
- If exposure has occurred, the customer must certify that decontamination has been accomplished and that no radioactivity is detectable by survey equipment.
- Any product being returned to the YSI Repair Center should be packed securely to prevent damage.
- Cleaning must be completed and certified on any product before returning it to YSI.

18.4 Packing Procedure

- Clean and decontaminate items to ensure the safety of the handler.
- Complete and include the Cleaning Certificate.
- Place the product in a plastic bag to keep out dirt and packing material.
- Use a large carton, preferably the original, and surround the product completely with packing material.
- Insure for the replacement value of the product.

Page 112 YSI 556 MPS YSI Incorporated

18.5 Warranty

The instrument is warranted for three years against defects in workmanship and materials when used for its intended purposes and maintained according to instructions. The probe module and cables are warranted for one year. The dissolved oxygen, temperature/conductivity, pH, and pH/ORP combination sensors are warranted for one year. Damage due to accidents, misuse, tampering, or failure to perform prescribed maintenance is not covered. The warranty period for chemicals and reagents is determined by the expiration date printed on their labels. Within the warranty period, YSI will repair or replace, at its sole discretion, free of charge, any product that YSI determines to be covered by this warranty.

To exercise this warranty, write or call your local YSI representative, or contact YSI Customer Service in Yellow Springs, Ohio. Send the product and proof of purchase, transportation prepaid, to the Authorized Service Center selected by YSI. Repair or replacement will be made and the product returned transportation prepaid. Repaired or replaced products are warranted for the balance of the original warranty period, or at least 90 days from date of repair or replacement.

Limitation of Warranty

This Warranty does not apply to any YSI product damage or failure caused by (i) failure to install, operate or use the product in accordance with YSI's written instructions, (ii) abuse or misuse of the product, (iii) failure to maintain the product in accordance with YSI's written instructions or standard industry procedure, (iv) any improper repairs to the product, (v) use by you of defective or improper components or parts in servicing or repairing the product, or (vi) modification of the product in any way not expressly authorized by YSI.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. YSI'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO REPAIR OR REPLACEMENT OF THE PRODUCT, AND THIS SHALL BE YOUR SOLE AND EXCLUSIVE REMEDY FOR ANY DEFECTIVE PRODUCT COVERED BY THIS WARRANTY. IN NO EVENT SHALL YSI BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY DEFECTIVE PRODUCT COVERED BY THIS WARRANTY.

19. Appendix F Ferrite Bead Installation

WARNING: If you are using your YSI 556 in a European Community (CE) country or in Australia or New Zealand, you must attach a ferrite bead to the 655173 PC Interface Cable and the YSI 6117 Charger Adapter Cable in order to comply with the Residential, Commercial and Light Industrial Class B Limits for radio-frequency emissions specified in EN55011 (CISPR11) for Industrial, Scientific and Medical laboratory equipment. These ferrite assemblies are supplied as part of cable kits.

- **1.** Make a small loop (approximately 5 cm in diameter) in the cable near the YSI 556 MS-19 connector.
- **2.** Lay the open ferrite bead assembly under the loop with the cable cross-over position within the cylinder of the ferrite bead.




Figure 19.1 Ferrite Bead Installation

- **3.** Snap the two pieces of the bead together making certain that the tabs lock securely.
- **4.** When the installation is complete, the 655173 and 6117 cables should resemble the following drawings.

Customer Service Appendix E




Figure 19.2 Cables with Ferrite Beads

20. Appendix G EcoWatch

EcoWatchTM for WindowsTM must be used as the PC software interface to the YSI 556 MPS. EcoWatch is a powerful tool that can also be used with YSI 6-series sondes. Many features of the software will only be utilized by advanced users or are not relevant to the 556 MPS at all. This section is designed in tutorial format to familiarize you with the commonly used features of EcoWatch so that it will be possible to:

- Upload data from a 556 MPS to a PC
- Assemble plots and reports of your data
- Zoom in on certain segments of the plots of your data to facilitate analysis
- Show statistical data for your studies
- Export data in spreadsheet-compatible formats
- Print plots and reports

The advanced features of EcoWatch can be explored by downloading a 6-series manual from the YSI Web Site (www.ysi.com), purchasing a hard copy of the manual through YSI Customer Service (Item # 069300), or utilizing the on-line help feature of the software.

20.1 Installing EcoWatch for Windows

EcoWatch for Windows is available at no cost via a download from the YSI Web Site – www.ysi.com


20.2 EcoWatch Tutorial

This EcoWatch tutorial is designed to teach you the commonly used operations associated with the software when used with your 556 MPS.

After you have uploaded a file, Refer to Section 8.4 Upload to PC, you will see two files in the C:\ECOWWIN\DATA directory; the file you transferred and a file supplied by YSI designated SAMPLE.DAT. This SAMPLE.DAT file is referred to in the remainder of this tutorial section. After following the instructions below for the analysis of SAMPLE.DAT, you apply the same analysis to the data file which was uploaded from your 556 MPS to assure that you are familiar with the basic features and capabilities of EcoWatch for Windows.

To start the analysis of the SAMPLE.DAT file, note that a shortened menu


bar is visible and many of the tools in the toolbar appear dimmed or "grayed out" before any file is opened (see below).



Full activation of EcoWatch features will be realized after a file is opened. To open the sample data file:

- 1. Click the File menu button in the toolbar.
- **2.** Select the **SAMPLE.DAT** file.
- 3. Click **OK** to open the file.

Appendix G EcoWatch




Note that the data in this file appears as a graph of temperature, specific conductance, dissolved oxygen, pH, ORP, and depth, all versus time. The graphs are scaled automatically so that all data fits comfortably on the computer screen. Note also that this data file was obtained with a 6-series sonde for which a depth sensor is available. Depth is NOT a current parameter for the 556 MPS.


The **Table** and **Graph** buttons on the toolbar are on/off switches that are used to display or hide the graph and table pages respectively. When displaying a graph and a table at the same time, you can control the relative size of the two pages by placing the cursor over the small bar that separates them and

then dragging it to the desired location. Click the **Table** button to generate the following dual display of data.

EcoWatch Appendix G




Now click the **Graph** button (turn it off) to display only a report of your data as shown below. Note that the size of the report can be varied by clicking on the and buttons in the Toolbar.




EcoWatch

Now return to the original graphic display by toggling the **Table** button "off" and **Graph** button "on".




From the **Setup** menu, click **Graph**. Click **2 Traces per Graph** and notice that the parameters are now graphed in pairs for easy comparison of parameters.



Click 1 Trace per Graph to return the display to the original setting. Move the cursor to any position in the graph, then click and hold the right mouse button.

Page 120 YSI 556 MPS YSI Incorporated


EcoWatch Appendix G



Note that the exact measurements for this point in time are displayed to the left of the graph. While holding down the right mouse button, move to another area on the graph. Notice how the measurements change as you move. When you release the mouse button, the display returns to normal.


To view statistical information for the study, click the **Statistics** button on the toolbar. On the statistics window, click on any min or max value to display the time when it occurred.

Appendix G EcoWatch



After viewing statistics, click the "x" at the upper right to close the window and return to the normal display.


Now click on the delimiter icon in the toolbar and then move the displayed icon to the graph. Click at the two points shown by dotted lines in the display below, being sure that the first click is to the left of the second.



The data between the two selected points will then be graphed in higher resolution as shown below.


Page 122 YSI 556 MPS YSI Incorporated

EcoWatch Appendix G




To return to the complete data set, select **Graph** from the toolbar and then click **Cancel Limits**.

Now select the icon from the Toolbar to create a new data file which will allow your data to be imported into spreadsheets. Select the default export settings for a Comma Delimited File (.CDF) and click OK. A new spreadsheet-importable file (SAMPLE.CDF) is now present in the same folder as the SAMPLE.DAT file.




Now select the icon from the toolbar to print the plot. Accept the default settings and click OK to complete the printing operation.

Appendix G EcoWatch



Finally, end the tutorial by saving the **Data Display** in the format shown. From the File menu, click **Save Data Display**.



Then type "Default" for the file name and click **Save**. The parameters, colors, format, and x-axis time interval associated with the current display are now saved and can be accessed any time in the future. Nine different data displays may be saved for any data file. You can easily switch between various displays of the data. The data files can be accessed by clicking **Load Data Display** from the file menu and then selecting the desired presentation.

20.2.1 Summary of Toolbar Capability

The EcoWatch toolbar includes buttons for some of the most common commands in EcoWatch, such as File Open. To display or hide the toolbar,

Page 124 YSI 556 MPS YSI Incorporated

Appendix G

open the **View** menu and click on the **Toolbar** command. A check mark appears next to the menu item when the toolbar is displayed.

The toolbar is displayed across the top of the application window, below the menu bar.



Click to:

Open an existing data file (.DAT). EcoWatch displays the **Open** dialog box, in which you can locate and open the desired file.

Save the working Data Display of the active data file. EcoWatch displays the **Save Data Display** dialog box in which you can overwrite existing Data Display or save to a new one.

Export data as a graph in Window Meta File (.WMF) format or as data in Comma Delimited (.CDF) format.

Copy the whole graph page or data from the selection on the table to the clipboard.

Print the active graph page or table page depending on which one is currently active.

Open a new terminal window to communicate with the sonde.

Access context sensitive help (Shift+F1).

Toggle table window during file processing.

Toggle graph window during file processing.

Display study statistics.

Display study info.

Limit the data to be processed.

Enlarge a selective portion of graph.

Appendix G EcoWatch

Center the graph under the cursor.

Enlarge graph of table 20%.

Reduce graph of table 20%.

Return graph or table to its normal size (unzoom).

Redraw the graph.

20.2.2 Other capabilities

The above tutorial and function list for the toolbar provide basic information to allow you to view and analyze the field data which was stored in your 556 MPS. Some of the other commonly used capabilities of EcoWatch which the user may want to explore are listed below:

- Customize the units for each parameter, e.g., report uS/cm instead of mS/cm for conductivity.
- Customize the order of parameters in each plot or report.
- Customize the colors and fonts of each data display.
- Manually scale the y-axis sensitivity for each parameter.
- Merging of two or more data files with compatible parameter formats
- View information about the study such as number of points, instrument serial number, etc. which was stored in the 556 with the data.
- Print data reports in different statistical formats.
- Create plots of parameter vs. parameter rather than parameter vs. time.

These additional features of EcoWatch for Windows are explained in detail in the YSI 6-series manual (which can be downloaded at no cost from the YSI Web Site as described above) and the Help selection in the EcoWatch menu bar. To purchase a hard copy of the 6-series manual, contact YSI Customer Service using the contact information in *Appendix E Customer Service*.

Page 126 YSI 556 MPS YSI Incorporated

21. Appendix H Calibration Record Information

When your YSI 556 MPS sensors are initially calibrated, relevant information about the sensors will be stored in a separate file in the YSI 556 MPS memory.

NOTE: This file, by default, will have the name "556 Circuit Board Serial Number.glp." The circuit board serial number is assigned at the factory and has a hexadecimal format such as 000080A4. Thus the default calibration record file would be designated 00080A4.glp. Refer to Section 10.7 GLP Filename to change the filename.

The information in the calibration record will track the sensor performance of your instrument and should be particularly useful for programs operating under Good Laboratory Practices (GLP) protocols.

21.1 Viewing the Calibration Record (.glp) File

NOTE: Make certain that you have performed a calibration on at least one of the sensors associated with your YSI 556 MPS.

Follow the procedures outlined in Section 8.3 View File.

21.2 Uploading the Calibration Record (.glp) File

NOTE: Make certain that you have performed a calibration on at least one of the sensors associated with your YSI 556 MPS.

Follow the procedures outlined in Section 8.4 Upload to PC.

21.3 Understanding the Calibration Record (.glp) File

- 1. Open a calibration record file. Refer to Section 8.3 View File.
- **2.** Use the arrow keys to scroll horizontally and/or vertically to view all the data.




Figure 21.1Calibration Record Screen 1




Figure 21.2 Calibration Record Screen 2

NOTE: Each sensor (not parameter) is characterized by either 1 line (Conductivity, Dissolved Oxygen, ORP, TDS, or Barometer (Optional)) or 2 lines (pH) of calibration documentation.

The left hand portion of each calibration entry shows the date and time that a calibration of a particular sensor was performed. In addition, each calibration entry is characterized by the instrument serial number, as defined by YSI. See Figure 21.1 Calibration Record Screen 1. The right hand portion shows the YSI designation of the calibration constants and their values after their calibration has been performed. A more detailed description of the calibration constants is provided below:

Page 128 YSI 556 MPS YSI Incorporated

Calibration Record Information

Appendix H

- Conductivity Gain A relative number which describes the sensitivity of the sensor. Basically, the value represents the calculated cell constant divided by the typical value of the cell constant (5 cm⁻¹).
- **DO Gain** A relative number which describes the sensitivity of the sensor. Basically, the value represents the sensor current at the time of calibration divided by the typical value of the sensor current (15 uA).
- **pH Gain** A number which basically represents the sensitivity of the pH sensor. To remove the effect of temperature on the slope of the relationship of probe output in mv versus pH, the value of pH/mv is multiplied by the temperature in degrees Kelvin (K).
- **pH Offset** A number which basically represents the offset (or intercept) of the relationship of probe output in mv versus pH, the value of pH is multiplied by the temperature in degrees Kelvin (K).

Anytime you perform a calibration, information concerning the calibration constants will be logged to the Calibration Record file (.glp file). However, if the **Delete All Files** command is used, Refer to Section 8.6 Delete All Files, the Calibration Record file will also be lost. It is critical that this file should be uploaded to your PC prior to issuing a **Delete All Files** command. Refer to Section 8.4 Upload to PC.



YSI Environmental 1700/1725 Brannum Lane Yellow Springs, OH 45387 USA 937.767.7241 937.767.9353 fax environmental@YSI.com www.YSI.com

Item # 655279
Rev D
Drawing # A655279
August 2009
©2009 YSI Incorporated